

Connecting BayStack AN and ANH Systems to a Network

Router Software Version 10.0
Site Manager Software Version 4.0

Part No. 112953 Rev. A
January 1996



Copyright © 1988–1996 Bay Networks, Inc.

All rights reserved. Printed in the USA. January 1996.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Bay Networks, Inc.

The software described in this document is furnished under a license agreement and may only be used in accordance with the terms of that license. A summary of the Software License is included in this document.

Restricted Rights Legend

Use, duplication, or disclosure by the United States Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

Notice for All Other Executive Agencies

Notwithstanding any other license agreement that may pertain to, or accompany the delivery of, this computer software, the rights of the United States Government regarding its use, reproduction, and disclosure are as set forth in the Commercial Computer Software-Restricted Rights clause at FAR 52.227-19.

Trademarks of Bay Networks, Inc.

ACE, AFN, BCN, BLN, BN, CN, FRE, LN, Optivity, SynOptics, SynOptics Communications, Wellfleet and the Wellfleet logo are registered trademarks and AN, ANH, ASN, BaySIS, BayStack, BCNX, BLNX, BNX, EZ Internetwork, EZ LAN, FN, PathMan, PhonePlus, PPX, Quick2Config, RouterMan, SPEX, Bay Networks, Bay Networks Press, the Bay Networks logo and the SynOptics logo are trademarks of Bay Networks, Inc.

Third-Party Trademarks

All other trademarks and registered trademarks are the property of their respective owners.

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, Bay Networks, Inc. reserves the right to make changes to the products described in this document without notice.

Bay Networks, Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

Portions of the code in this software product are Copyright © 1988, Regents of the University of California. All rights reserved. Redistribution and use in source and binary forms of such portions are permitted, provided that the above copyright notice and this paragraph are duplicated in all such forms and that any documentation, advertising materials, and other materials related to such distribution and use acknowledge that such portions of the software were developed by the University of California, Berkeley. The name of the University may not be used to endorse or promote products derived from such portions of the software without specific prior written permission.

SUCH PORTIONS OF THE SOFTWARE ARE PROVIDED “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

In addition, the program and information contained herein are licensed only pursuant to a license agreement that contains restrictions on use and disclosure (that may incorporate by reference certain limitations and notices imposed by third parties).

Bay Networks Software License



Note: *This is Bay Networks basic license document. In the absence of a software license agreement specifying varying terms, this license — or the license included with the particular product — shall govern licensee’s use of Bay Networks software.*

This Software License shall govern the licensing of all software provided to licensee by Bay Networks (“Software”). Bay Networks will provide licensee with Software in machine-readable form and related documentation (“Documentation”). The Software provided under this license is proprietary to Bay Networks and to third parties from whom Bay Networks has acquired license rights. Bay Networks will not grant any Software license whatsoever, either explicitly or implicitly, except by acceptance of an order for either Software or for a Bay Networks product (“Equipment”) that is packaged with Software. Each such license is subject to the following restrictions:

1. Upon delivery of the Software, Bay Networks grants to licensee a personal, nontransferable, nonexclusive license to use the Software with the Equipment with which or for which it was originally acquired, including use at any of licensee’s facilities to which the Equipment may be transferred, for the useful life of the Equipment unless earlier terminated by default or cancellation. Use of the Software shall be limited to such Equipment and to such facility. Software which is licensed for use on hardware not offered by Bay Networks is not subject to restricted use on any Equipment, however, unless otherwise specified on the Documentation, each licensed copy of such Software may only be installed on one hardware item at any time.
2. Licensee may use the Software with backup Equipment only if the Equipment with which or for which it was acquired is inoperative.
3. Licensee may make a single copy of the Software (but not firmware) for safekeeping (archives) or backup purposes.
4. Licensee may modify Software (but not firmware), or combine it with other software, subject to the provision that those portions of the resulting software which incorporate Software are subject to the restrictions of this license. Licensee shall not make the resulting software available for use by any third party.
5. Neither title nor ownership to Software passes to licensee.
6. Licensee shall not provide, or otherwise make available, any Software, in whole or in part, in any form, to any third party. Third parties do not include consultants, subcontractors, or agents of licensee who have licensee’s permission to use the Software at licensee’s facility, and who have agreed in writing to use the Software only in accordance with the restrictions of this license.
7. Third-party owners from whom Bay Networks has acquired license rights to software that is incorporated into Bay Networks products shall have the right to enforce the provisions of this license against licensee.
8. Licensee shall not remove or obscure any copyright, patent, trademark, trade secret, or similar intellectual property or restricted rights notice within or affixed to any Software and shall reproduce and affix such notice on any backup copy of Software or copies of software resulting from modification or combination performed by licensee as permitted by this license.

Bay Networks Software License *(continued)*

9. Licensee shall not reverse assemble, reverse compile, or in any way reverse engineer the Software. [Note: For licensees in the European Community, the Software Directive dated 14 May 1991 (as may be amended from time to time) shall apply for interoperability purposes. Licensee must notify Bay Networks in writing of any such intended examination of the Software and Bay Networks may provide review and assistance.]
10. Notwithstanding any foregoing terms to the contrary, if licensee licenses the Bay Networks product "Site Manager," licensee may duplicate and install the Site Manager product as specified in the Documentation. This right is granted solely as necessary for use of Site Manager on hardware installed with licensee's network.
11. This license will automatically terminate upon improper handling of Software, such as by disclosure, or Bay Networks may terminate this license by written notice to licensee if licensee fails to comply with any of the material provisions of this license and fails to cure such failure within thirty (30) days after the receipt of written notice from Bay Networks. Upon termination of this license, licensee shall discontinue all use of the Software and return the Software and Documentation, including all copies, to Bay Networks.
12. Licensee's obligations under this license shall survive expiration or termination of this license.

Contents

About This Guide

Audience	xv
Before You Begin	xvi
Where to Find AN and ANH Information	xvi
Bay Networks Customer Support	xvii
CompuServe	xvii
InfoFACTS	xviii
World Wide Web	xviii
How to Get Help	xix
Conventions	xix
Ordering Bay Networks Publications	xx
Acronyms	xx

Chapter 1

Hardware and Software Overview

Access Node Hardware	1-1
AN Models	1-1
ANH Models	1-3
Access Node Software	1-5
Software Management Tools	1-5
Router Software	1-6
Boot Configuration Options	1-6
The Boot Process	1-9
Network Boot	1-9
Getting an IP Address	1-9
Getting Kernel Image and Configuration Files	1-13
Local Boot	1-15
Configuring the Initial IP Interface	1-16

Chapter 2

Selecting the Boot Configuration

Booting the Router for the First Time	2-1
EZ-Install	2-2
Netboot	2-2
Local Boot	2-3
Recommendations	2-3
Booting the Router Routinely	2-3
Netboot	2-3
Directed Netboot	2-4
Local Boot	2-5
Recommendations	2-5
Completing a Startup Option	2-6
EZ-Install	2-6
Netboot	2-7
Directed Netboot	2-8
Local Boot	2-9

Chapter 3

Setting Up a UNIX Boot Server

Setting Up a BOOTP Server	3-1
Copying the BOOTPD Program on Sun Workstations	3-2
Setting Up BOOTP Sockets	3-2
Setting Up BOOTPD to Run	3-3
Setting Up BOOTPD to Respond to Routers	3-3
Editing the bootptab File	3-4
Verifying Consistent BOOTP Service	3-8
Setting Up a TFTP Server	3-8
Providing TFTP Access to the Root Directory	3-8
Restricting TFTP Access to a Specified Directory	3-9
Adding a TFTP User for an HP 9000	3-10
Setting Up Static Routes to Next-Hop Routers	3-10
Editing the inetd.conf File	3-11
Verifying the Routes	3-11
Loading the Changes into Memory	3-11
What to Do Next	3-12

Chapter 4

Configuring Network Booting

Preparing Configuration and Image Files	4-2
Creating Configuration Files	4-2
Preparing an Image	4-3
Enabling Netboot or Directed Netboot	4-4
Netboot and Directed Netboot Parameters	4-5
Configuring a Netboot or Directed Netboot Interface	4-8
Netboot Interface Parameters	4-11
Setting Up Routing Paths for Netboot	4-14
Enabling Router Interfaces	4-14
Creating BOOTP Relay Agent Forwarding Tables	4-15
BOOTP Relay Agent Interface Parameters	4-18
Creating the BOOTP Client Interface Table	4-19
BOOTP Client Interface Parameters	4-21

Chapter 5

Configuring an Access Node as a Network Boot Client

Working with a Person at the AN/ANH Site	5-1
Configuring the Router Boot Source	5-2
bconfig Command Format	5-2
bconfig Command Examples	5-3
Configuring the Netboot Interface	5-3
Configuring an IP Synchronous Interface for Network Booting	5-4
Configuring an Ethernet Interface for Network Booting	5-5
Enabling and Disabling Interfaces with ifconfig	5-6
ifconfig Command Examples	5-7
What to Do Next	5-7

Chapter 6

Configuring AN and ANH Features

Managing ANH Repeater Ports	6-1
Testing and Resetting Repeater Ports	6-1
Repeater Port Group Parameter Descriptions	6-3
Enabling and Disabling ANH Repeater Ports	6-4
Configuring an N11 Data Collection Module	6-7
About the N11 DCM	6-7

About Remote Network Monitoring (RMON)	6-8
The RMON Groups	6-8
For More Information about RMON	6-10
Enabling the DCM	6-11
DCM Global Parameter Descriptions	6-13
Managing the DCM Using Site Manager	6-17
Activating DCM	6-17
Disabling DCM	6-18
Booting DCM	6-18
Changing DCM Configuration Parameters	6-19
Deleting the DCM Software Subsystem	6-21
Managing the DCM Board Using the Technician Interface	6-22
Changing DCM Configuration Parameters	6-22
RMON Implementation Notes	6-23
RMON Interoperability Issues	6-23
RMON Memory Use	6-24
Interoperability Issues and Memory Use for RMON Groups	6-24
Statistics Group	6-25
History Group	6-25
Host Group	6-26
HostTopN Group	6-27
Matrix Group	6-27
Filter and Capture Groups	6-28

Appendix A

Troubleshooting Network Boot Problems

Solving Startup Problems	A-1
Router Fails to Get IP Address	A-2
Upstream Router Not Receiving BOOTP Requests	A-2
Upstream Router Not Sending BOOTP Responses	A-2
Router Fails to Netboot	A-3
Upstream Router Not Receiving BOOTP Requests	A-3
Router Not Sending BOOTP Responses	A-4
BOOTP Server Not Sending BOOTP Responses	A-4
Router Fails to Perform Directed Netboot	A-5
Router Netboots, but Fails to Load Applications	A-5

Identifying Remote Connectivity Problems	A-7
Displaying Messages from the AN/ANH Console	A-7
Displaying Statistics and Error Messages	A-8
Guidelines for Using Packet Capture	A-8
Guidelines for Using a LAN Protocol Analyzer	A-9
Resolving Connectivity Problems	A-9
Displaying Parameter Settings	A-10
Debugging the BOOTP Server	A-11
Verifying the BOOTP Server Setup	A-12
Displaying the BOOTP Server's IP Routes	A-13
Displaying the Number of Packets Forwarded and Dropped	A-14
Quick Get Instructions	A-14
Technician Interface Instructions	A-14
Maintaining the Router Software	A-15
Upgrading the Software Image	A-15
Restoring a Local File System	A-16

Appendix B

Local Boot: The Quick-Start Procedure

What Is Quick-Start?	B-1
Using the Quick-Start Worksheets	B-2
Global Information Worksheet	B-3
Router Protocol Worksheets	B-5
Wide-Area Protocol Worksheets	B-8
Running the Quick-Start Script	B-12

Appendix C

Implementation Notes

Hints	C-1
Notes	C-2
Network Configuration Options	C-3
Ensuring Ethernet Network Compliance	C-3
Network Path Containing Three Repeaters	C-4
Network Path Containing Four Repeaters	C-4
Configuring a Single ANH	C-4
Configuring Multiple Hubs	C-6

Configuring an AUI Port	C-7
Connecting the AUI Port to a Fiber-Optic Backbone	C-8
Connecting the AUI Port to a Coaxial Backbone	C-9

Index

Figures

Figure 1-1.	Getting an IP Address from a Bay Networks Standard Circuit or a Frame Relay PVC in Direct Access Mode	1-11
Figure 1-2.	Getting an Address from a PVC in Group Access Mode	1-12
Figure 1-3.	Getting the Pathnames of the Kernel and Configuration Files	1-13
Figure 1-4.	Getting the Configuration File	1-14
Figure 1-5.	Getting the Kernel	1-15
Figure 1-6.	Establishing an IP Network Interface	1-16
Figure 3-1.	Sample bootptab File	3-7
Figure 4-1.	Edit Netboot Global Parameters Window	4-4
Figure 4-2.	Netboot Interfaces Window	4-8
Figure 4-3.	AN/ANH Netboot Interface Window	4-9
Figure 4-4.	Netboot Interfaces Window	4-10
Figure 4-5.	Enabling BOOTP in a Sample Network	4-14
Figure 4-6.	BOOTP Relay Agent Interface Table Window	4-16
Figure 4-7.	BOOTP Relay Agent Forwarding Table Window	4-17
Figure 4-8.	BOOTP Addresses Window	4-17
Figure 4-9.	BOOTP Client Interface Table Window	4-20
Figure 4-10.	BOOTP Client Interface Address Window	4-20
Figure 6-1.	Selecting the Repeater Hub Group Parameters Window	6-2
Figure 6-2.	Group Parameters Window	6-2
Figure 6-3.	Selecting the Repeater Port Status Window	6-4
Figure 6-4.	8-Port ANH Port Status Window	6-5
Figure 6-5.	12-Port ANH Port Status Window	6-6
Figure 6-6.	Creating the DCM Software Configuration from the Configuration Manager	6-11
Figure 6-7.	Edit DCM Parameters Window	6-12
Figure 6-8.	Selecting the DCM Parameters Window	6-19
Figure 6-9.	Edit DCM Parameters Window	6-20

Figure 6-10. Deleting DCM from the Configuration Manager Window 6-21

Figure B-1. Starting the IP Interface Test B-14

Figure C-1. Typical Single-ANH Configuration C-5

Figure C-2. Connecting the ANH with Other Hubs C-7

Figure C-3. Connecting Two ANH Systems Using 10Base-FL Transceivers C-8

Figure C-4. Connecting ANH Systems through a Coaxial Backbone C-9

Tables

Table 1-1.	BayStack AN Configurations	1-2
Table 1-2.	BayStack ANH Configurations	1-4
Table 1-3.	Summary of Boot Options	1-7
Table 3-1.	BOOTPD Tags for a Router Host Name	3-5
Table 3-2.	BOOTPD Tags for a Boot Image Name	3-6
Table 3-3.	Providing TFTP Access to Root and All Subdirectories	3-9
Table 3-4.	Restricting TFTP Access to One Directory	3-9
Table 5-1.	bconfig Command Settings	5-2
Table 5-2.	ifconfig Command Settings for a Synchronous Interface	5-4
Table 5-3.	ifconfig Command Settings for an Ethernet Interface	5-6
Table 5-4.	ifconfig Settings to Enable and Disable Netboot Interfaces	5-6
Table 6-1.	DRAM and RMON Memory Size	6-24
Table 6-2.	Maximum Number of Hosts	6-26
Table 6-3.	Default Size for Capture Buffer	6-28
Table A-1.	BOOTP Messages	A-12
Table B-1.	Quick-Start Commands	B-13
Table C-1.	IEEE 802.3 Maximum Segment Links	C-4

About This Guide

Read this guide if you are responsible for connecting a Bay Networks BayStack™ Access Node (AN™) or Access Node Hub (ANH™) router to a managed network.

Connecting BayStack AN and ANH Systems to a Network offers

- An overview of AN and ANH hardware and software (Chapter 1)
- A description of network booting (Chapter 2)
- Instructions for setting up a UNIX workstation as a BOOTP server (Chapter 3)
- Instructions for configuring Site Manager to support network booting (Chapter 4)
- Instructions for configuring the AN or ANH for network booting (Chapter 5)
- Instructions for managing ANH repeater ports (Chapter 6)
- Instructions for configuring an N11 Data Collection Module (DCM) for RMON statistics gathering (Chapter 6)
- Troubleshooting guidelines and procedures (Appendix A)
- Worksheets for completing the Quick-Start procedure (Appendix B)
- Implementation hints and notes (Appendix C)

Audience

Written for system and network managers, this guide assumes that you have a working knowledge of

- Ethernet and IEEE 802.3 networks and their physical layer components
- Site Manager
- A text editor on a UNIX workstation

Before You Begin

Before using this guide, you (or a person at the router site) must install the AN or ANH hardware and network connections, as described in one of the following guides:

- *Installing and Starting BayStack AN Routers*
- *Installing and Starting 8-Port BayStack ANH Systems*

Where to Find AN and ANH Information

Use this guide in conjunction with other Bay Networks documentation to set up and manage AN and ANH systems. Refer to the following when looking for specific information.

For Information on This	Look Here
Installing BayStack AN hardware	<i>Installing and Starting BayStack AN Routers</i>
Installing 8-port BayStack ANH hardware	<i>Installing and Starting 8-Port BayStack ANH Systems</i>
Learning about AN and ANH software and the four startup/boot options	Chapter 1 in this guide
Choosing the startup option for an AN or ANH	Chapter 2 in this guide
Setting up a UNIX workstation as a BOOTP server to support a network boot option	Chapter 3 in this guide
Configuring Site Manager to support a network boot option	Chapter 4 in this guide
What to do at the AN/ANH site to support a network boot option	Chapter 5 in this guide
Configuring a Data Collection Module	Chapter 6 in this guide
Preparing for the Quick-Start (local boot) procedure	Appendix B in this guide
Completing any of the four startup options at the AN/ANH site	<i>Installing and Starting BayStack AN Routers or Installing and Starting 8-Port BayStack ANH Systems</i>

(continued)

For Information on This	Look Here
Configuring and managing an AN or ANH after it is connected to the network	<i>Configuring Routers and Managing Routers and BNX Platforms</i>
Reconfiguring AN/ANH netboot interfaces	Chapter 5 in this guide
Considerations for setting up an AN or ANH	Appendix C in this guide
Resolving problems with the network boot process	Appendix A in this guide
Troubleshooting all other problems	<i>Troubleshooting Routers</i>

Bay Networks Customer Support

Bay Networks provides live telephone technical support to our distributors, resellers, and service-contracted customers from two U.S. and three international support centers. If you have purchased your Bay Networks product from a distributor or authorized reseller, contact the technical support staff of that distributor or reseller for assistance with installation, configuration, troubleshooting, or integration issues.

Customers also have the option of purchasing direct support from Bay Networks through a variety of service programs. The programs include priority access telephone support, on-site engineering assistance, software subscription, hardware replacement, and other programs designed to protect your investment.

To purchase any of these support programs, including PhonePlus™ for 24-hour telephone technical support, call 1-800-2LANWAN. Outside the U.S. and Canada, call (408) 764-1000. You can also receive information on support programs from your local Bay Networks field sales office, or purchase Bay Networks support directly from your reseller. Bay Networks provides several methods of receiving support and information on a nonpriority basis through the following automated systems.

CompuServe

Bay Networks maintains an active forum on CompuServe. All you need to join us online is a computer, a modem, and a CompuServe account. We also recommend using the CompuServe Information Manager software, available from CompuServe.

The Bay Networks forum contains libraries of technical and product documents designed to help you manage and troubleshoot your Bay Networks products. Software agents and patches are available, and the message boards are monitored by technical staff and can be a source for problem solving and shared experiences.

Customers and resellers holding Bay Networks service contracts can visit the special libraries to acquire advanced levels of support documentation and software.

To open an account and receive a local dial-up number, call CompuServe at 1-800-524-3388 and ask for Representative No. 591.

- In the United Kingdom, call Freephone 0800-289378.
- In Germany, call 0130-37-32.
- In Europe (except for the United Kingdom and Germany), call (44) 272-760681.
- Outside the U.S., Canada, and Europe, call (614) 529-1349 and ask for Representative No. 591, or consult your listings for an office near you.

Once you are online, you can reach our forum by typing the command GO BAYNETWORKS at any ! prompt.

InfoFACTS

InfoFACTS is the Bay Networks free 24-hour fax-on-demand service. This automated system contains libraries of technical and product documents designed to help you manage and troubleshoot your Bay Networks products. The system can return a fax copy to the caller or to a third party within minutes of being accessed.

World Wide Web

The World Wide Web (WWW) is a global information system for file distribution and online document viewing via the Internet. You need a direct connection to the Internet and a Web Browser (such as Mosaic or Netscape).

Bay Networks maintains a WWW Home Page that you can access at <http://www.baynetworks.com>. One of the menu items on the Home Page is the Customer Support Web Server, which offers technical documents, software agents, and an E-mail capability for communicating with our technical support engineers.

How to Get Help

For additional information or advice, contact the Bay Networks Technical Response Center in your area:

United States	1-800-2LAN-WAN
Valbonne, France	(33) 92-966-968
Sydney, Australia	(61) 2-903-5800
Tokyo, Japan	(81) 3-328-005

Conventions

angle brackets (< >)	Indicate that you choose the text to enter based on the description inside the brackets. Do not type the brackets when entering the command. Example: if command syntax is ping <ip_address> , you enter ping 192.32.10.12
arrow character (➔)	Separates menu and option names in instructions. Example: Protocols➔AppleTalk identifies the AppleTalk option in the Protocols menu.
bold text	Indicates text that you need to enter and command names in text. Example: Use the dinfo command.
brackets ([])	Indicate optional elements. You can choose none, one, or all of the options.
<i>italic text</i>	Indicates variable values in command syntax descriptions, new terms, file and directory names, and book titles.
quotation marks (“ ”)	Indicate the title of a chapter or section within a book.
screen text	Indicates data that appears on the screen. Example: Set Bay Networks Trap Monitor Filters

ellipsis points	Horizontal (. . .) and vertical (:) ellipsis points indicate omitted information.
vertical line ()	Indicates that you enter only one of the parts of the command. The vertical line separates choices. Do not type the vertical line when entering the command. Example: If the command syntax is show at routes nets , you enter either show at routes or show at nets , but not both.

Ordering Bay Networks Publications

To purchase additional copies of this document or other Bay Networks publications, order by part number from Bay Networks Press™ at the following numbers. You may also request a free catalog of Bay Networks Press product publications.

Phone:	1-800-845-9523
FAX - U.S./Canada:	1-800-582-8000
FAX - International:	1-916-939-1010

Acronyms

AN	Access Node
ANH	Access Node Hub
ANSI	American National Standards Institute
ARP	Address Resolution Protocol
ASN	Access Stack Node
AUI	attachment unit interface
BOFL	Breath of Life
BOOTP	Bootstrap Protocol
BOOTPD	Boot Protocol Daemon
BRI	Basic Rate Interface
CHAP	Challenge Handshake Authentication Protocol
DCE	data communications equipment
DCM	Data Collection Module
DLCI	data link connection identifier

DLCMI	data link control management interface
DTE	data terminal equipment
FTP	File Transfer Protocol
HDLC	high-level data link control
IEEE	Institute of Electrical and Electronic Engineers
IP	Internet Protocol
IPX	Internet Packet Exchange
ISDN	Integrated Services Digital Network
LMI	Local Management Interface
LQR	Link Quality Reporting
MAC	media access control
MAU	media access unit
MIB	Management Information Base
MTU	Maximum Transmission Unit
NBMA	Non-Broadcast Multi-Access
NMM	network management module
OSPF	Open Shortest Path First
PAP	Password Authentication Protocol
PPP	Point-to-Point Protocol
PVC	permanent virtual circuit
RARP	Reverse Address Resolution Protocol
RFC	Request for Comments
RIP	Routing Information Protocol
RMON	remote monitoring
SAM	System Administration Manager
SMDS	Switched Multimegabit Data Services
SMIT	System Management Interface Tool
SNMP	Simple Network Management Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol
Telnet	Telecommunication Network
TFTP	Trivial File Transfer Protocol
TFTPD	Trivial File Transfer Protocol Daemon
UDP	User Datagram Protocol
UTP	unshielded twisted pair

Chapter 1

Hardware and Software Overview

The Bay Networks BayStack Access Node family of routers connects multiprotocol workgroups to corporate backbone networks. This chapter includes the following information about the Access Node:

- Hardware connections
- Software support
- Boot configuration options
- Boot process

Access Node Hardware

Bay Networks offers a series of Access Node products, including Access Node Hub (ANH) systems. AN and ANH models provide a variety of Ethernet, Token Ring, and synchronous network interfaces. Each also includes a service port (labeled CONSOLE) with DB-9 connector for local or remote access.

Tables [1-2](#) and [1-2](#) summarize the AN and ANH base and optional hardware and provide corresponding module names for creating Site Manager configuration files.

AN Models

The AN is available in the following basic configurations:

- One Ethernet AUI and two synchronous interfaces
- One Token Ring media access unit (MAU) and two synchronous interfaces
- One Ethernet, one Token Ring, and two synchronous interfaces

As optional upgrades, the AN also supports

- A third synchronous interface
- An ISDN BRI interface for direct (without terminal adapter) connection to the ISDN network
- A second Ethernet interface (*not* supported in Token Ring ANs)
- An N11 Ethernet Data Collection Module (DCM) for gathering RMON statistics (*not* supported in Token Ring ANs)



Note: When using an N11 DCM in the BayStack AN, the AN requires Router Software Version 9.00 or higher and Site Manager Software Version 3.00 or higher.

See Table 1-1 for a summary of AN hardware and the corresponding Site Manager module name for creating configuration files.

Table 1-1. BayStack AN Configurations

Base AN Interface Configuration	Upgrade Components	Site Manager Module Name
1 Ethernet (XCVR1) and 2 synchronous (COM1 and COM2) Order Nos. AE1001006, AE1001007, AE1001008	none	E/2S
	1 ISDN BRI (replaces COM2)	E/2S/BRI
	1 ISDN BRI with Floating B channel	E/2S/BRI+
	1 Ethernet DCM	E/2S/N11 DCM
	1 third synchronous interface	E/3S
	1 second Ethernet interface	2E/2S
	1 third synchronous interface and 1 Ethernet DCM	E/3S/N11 DCM
	1 ISDN BRI with Floating B channel and 1 Ethernet DCM	E/2S/BRI+/N11 DCM
	1 second Ethernet interface and 1 Ethernet DCM	2E/2S/N11 DCM

(continued)

Table 1-1. BayStack AN Configurations *(continued)*

Base AN Interface Configuration	Upgrade Components	Site Manager Module Name
1 Token Ring (TOKEN1) and 2 synchronous (COM1 and COM2) Order Nos. AE1101002, AE1101003 AE1101004	none	T/2S
	1 ISDN BRI (replaces COM2)	T/2S/BRI
	1 ISDN BRI with Floating B channel	T/2S/BRI+
	1 third synchronous interface	T/3S
1 Ethernet (XCVR1), 1 Token Ring (TOKEN1), and 2 synchronous (COM1 and COM2) Order Nos. AE1101006, AE1101007 AE1101008	none	E/T/2S
	1 ISDN BRI (replaces COM2)	E/T/2S/BRI
	1 third synchronous interface	E/T/3S
	1 ISDN BRI with Floating B channel	E/T/2S/BRI+
	1 Ethernet DCM	E/T/2S/N11 DCM
	1 ISDN BRI with Floating B channel and 1 Ethernet DCM	E/T/2S/BRI+/N11 DCM
	1 third synchronous interface and 1 Ethernet DCM	E/T/3S/N11 DCM

ANH Models

The ANH is available in 12 and 8 Ethernet hub repeater port configurations. The repeater interfaces include 10BaseT shielded or unshielded twisted pair (UTP) ports with RJ-45 modular connectors. The 8-port ANH also supports a 15-pin Attachment Unit Interface (AUI) connection to the Ethernet repeater.



Note: *The Ethernet repeater ports operate as a single interface. Software configuration parameters (for example, the port IP address) apply to all ports.*

Both the 12- and 8-port ANH models include two synchronous interfaces with 44-pin connectors (COM1 and COM2). These ports provide simultaneous and independent support for SDLC, X.21, EIA232, EIA449/422, or V.35

With optional upgrades installed, the BayStack ANH also supports

- An ISDN basic rate interface (BRI), providing direct connection to the ISDN network, as opposed to connecting via a terminal adapter. On some ANH models, the ISDN BRI disables the COM2 port.
- A third synchronous interface
- A second, nonrepeating Ethernet interface
- An N11 Ethernet Data Collection Module (DCM) for gathering RMON statistics. (8-port ANH only; the 12-port ANH does *not* support the DCM.)



Note: When using an N11 DCM, the ANH requires Router Software Version 9.00 or higher and Site Manager Software Version 3.00 or higher.

See [Table 1-2](#) for a summary of ANH hardware and the corresponding Site Manager module names for creating configuration files.

Table 1-2. BayStack ANH Configurations

Model	Base Interface Configuration	Added Components	Site Manager Name
8-port ANH Order Nos. AE1101010, AE1101011 AE1101012	1 Ethernet repeater (XCVR1) and 2 synchronous (COM1 and COM2)	none	8pt EHub/2S
		1 Ethernet DCM	8pt EHub/2S/N11 DCM
		1 third synchronous interface (COM3)	8pt EHub/3S
		1 second Ethernet interface (XCVR2)	8pt EHub/E/2S
		1 ISDN BRI with Floating B channel	8pt EHub/2S/BRI+
		1 third synchronous interface and 1 Ethernet DCM	8pt EHub/3S/N11 DCM
		1 second Ethernet interface and 1 Ethernet DCM	8pt EHub/E/2S/N11 DCM
		1 ISDN BRI, 1 Ethernet DCM	8pt EHub/2S/BRI+/N11 DCM
12-port ANH Order Nos. AE1101014, AE1101015 AE1101016	1 Ethernet repeater (XCVR1) and 2 synchronous (COM1 and COM2)	none	12Pt EHub/2S
		1 ISDN BRI (replaces COM2)	12Pt EHub/2S/BRI
		1 third synchronous interface	12Pt EHub/3S
		1 second Ethernet interface	12Pt EHub/E/2S
		1 ISDN BRI with Floating B channel	12Pt EHub/2S/BRI+

Access Node Software

Read this section for summary information about the AN/ANH router software. It describes

- Tools available for configuring and managing an AN/ANH
- Kernel and application files
- Boot configuration options

AN and ANH models support all major LAN and WAN protocols, standard IBM transport, and dialup services. A choice of protocol suites (IP Access Suite, Remote Office Suite, or Corporate Suite) provides site-specific software configurations at remote AN and ANH installations.

As for all Bay Networks routers, the Access Node family provides extensive MIB variable support, including

- Standard MIB II
- Bay Networks proprietary MIB
- Managed Hub (RFC 1516 MIB) for ANH models
- Remote Monitoring (RMON RFC 1757) for ANH models with a DCM option

Software Management Tools

You configure and manage an AN or ANH using

- The *Technician Interface*, a terminal-based command-line interface that operates in router memory. You run Technician Interface commands and scripts for SNMP-based MIB access from an attached console or from a remote console, via modem.
- The *Diagnostics Monitor*, a firmware diagnostics agent with a command-line interface. You use the Diagnostics Monitor to configure the router's boot configuration.
- *Site Manager* software, a platform-independent, SNMP-based router management and configuration application with a graphical user interface. You run Site Manager at a workstation that is connected, along with the router, to an IP network.

- *Optivity®/Internetwork*, a comprehensive, SNMP-based network management application for administering and troubleshooting large, complex networks. The Optivity/Internetwork package includes Site Manager, PathMan™, and RouterMan™ software.

Router Software

Before it can operate, the AN and ANH hardware must boot a *software image*. The software image is a group of executable files that operate the protocols the network requires. The AN/ANH software image, called *an.exe*, comprises the following executable startup files:

- A *krnl_an.exe* file that contains the operating system kernel.
- Application files — executable files needed to perform the functions specified in the configuration file. All application files have *.exe* filename extensions. (For example, the router needs an *ipx.exe* executable file to run IPX.)
- String files — compressed ASCII files needed when you use the Technician Interface to display the event log or Management Information Base (MIB) object names. Groups of string files remain in compressed format within the *an.exe* file until needed.

To bridge and route traffic, the AN/ANH also needs a *configuration file* that is tailored to your network. A configuration file is a binary system file that contains hardware and software configuration data. The default configuration file is named *config*.

Boot Configuration Options

This section summarizes your options for getting the AN/ANH software image file and configuration files.

An AN/ANH boots using one of four configured startup options. The differences among the four AN/ANH startup options are based on whether the router retrieves boot and configuration files over the network or from local memory.

Getting a software image or configuration file over the network is called *Netbooting*. Getting a file from the file system stored in local Flash memory is called *Local booting*.

To *initially* start up the AN or ANH, you use one of these boot configuration options:

- EZ-Install (the default)
- Netboot
- Local Boot

To start up the AN/ANH *after* the initial configuration, you use one of these options:

- Netboot
- Directed Netboot
- Local Boot

[Table 1-3](#) summarizes the four startup options. The next section, “[The Boot Process](#),” describes how each option works.

Table 1-3. Summary of Boot Options

Boot Option	Source for Software Image	Source for Config File	Description and Requirements
<i>EZ-Install</i>	Local (Flash memory)	Network (Synchronous connection)	The default option. The AN/ANH boots from a software image in local memory, then transmits a request for its IP address and configuration file through an attached synchronous interface. Next, a remote UNIX- or DOS-based workstation that is configured as a Boot Protocol (BOOTP) server downloads a customized configuration file; you save that configuration to Flash memory. Requires a communications link over an HDLC or Frame Relay interface. If EZ-Install fails, the router tries the Local Boot procedure.

(continued)

Table 1-3. Summary of Boot Options (*continued*)

Boot Option	Source for Software Image	Source for Config File	Description and Requirements
<i>Netboot</i>	Network (Synchronous or Ethernet connection)	Network (Synchronous or Ethernet connection)	The AN/ANH obtains all startup files from a remote UNIX- or DOS-based workstation that is configured as a BOOTP server. (Getting these files individually, rather than getting the entire <i>an.exe</i> file, minimizes the cost of line usage and prevents saturation of the router's memory.) Requires a local <i>an.exe</i> file, a local console connection, and a communications link over an HDLC, Frame Relay, or Ethernet interface. If Netboot fails, the router tries the Local Boot procedure.
<i>Directed Netboot</i>	Network (Synchronous or Ethernet connection)	Network (Synchronous or Ethernet connection)	The AN/ANH obtains all startup files from a remote UNIX- or DOS-based workstation that is configured as a Trivial File Transfer Protocol (TFTP) server. You specify the IP address of the TFTP server and the pathname of the startup files before booting. Requires a local console connection and a communications link over an HDLC, Frame Relay, or Ethernet interface. If Directed Netboot cannot retrieve the appropriate files, the router attempts normal Netboot. If this fails, the router tries Local Boot.
<i>Local Boot</i>	Local (Flash memory)	Local (Flash memory)	The AN/ANH boots using a software router image and configuration file stored in local memory. During the initial startup, the AN/ANH uses a generic startup configuration file. You customize the default configuration file by assigning an IP address to an interface and running an installation script; this is called the <i>Quick-Start</i> procedure. Quick-Start requires a local console and an active IP network connection.

The Boot Process

An AN/ANH boots using its configured startup option. The default configuration for a new AN or ANH is *EZ-Install*.

(If an initial boot attempt fails, the router attempts to boot once using a different option. If both boot attempts fail, you must troubleshoot the problem and reboot the router as described in [Appendix A](#).)

The following sections describe the boot process for network and local boot options.

Network Boot

When booting over the network using EZ-Install, Netboot, or Directed Netboot, the AN or ANH essentially

1. Powers on.
2. Determines its IP address.
3. Obtains a software kernel file and/or configuration file by communicating with a configured BOOTP server on the IP network.
4. Reboots, using the newly transferred image.
5. Gets application and string files over the network as it needs them.
6. Begins bridging and routing network traffic in accordance with the configuration file.

The following sections describe in more detail the key steps in this process: obtaining an IP address and downloading the image and configuration files.

Getting an IP Address

The AN or ANH gets its IP address from a central-site upstream router.



Note: *The upstream router must have a circuit running Bay Networks Standard Point-to-Point Protocol (PPP) using HDLC or a Frame Relay permanent virtual circuit (PVC).*

Obtaining the IP Address Manually (Netboot and Directed Netboot)

For Netboot and Directed Netboot, you configure the IP address manually. [Chapter 4](#) describes how to use Site Manager to configure Netboot interfaces. [Chapter 5](#) describes how to configure the netboot interfaces using the Technician Interface.

Obtaining the IP Address Automatically (EZ-Install)

During the EZ-Install process, the router obtains its address automatically, as described below.

1. When you power on the AN/ANH, it runs a set of diagnostic tests.
2. The AN/ANH sends a BOOTP request to the upstream router for an IP address and subnet mask.

The AN/ANH issues the request through all synchronous ports at about the same time, even if cables are not connected to these ports. Each port successively tries the following protocols until it receives a response:

- Bay Networks Standard PPP using HDLC (high-level datalink control) encapsulation
- Frame Relay Annex D
- Frame Relay Local Management Interface (LMI)
- Frame Relay Annex A

The AN/ANH makes two attempts for each protocol. If it does not receive a response in approximately 4 minutes, the AN/ANH boots the default image and configuration file in its local file system, as described in the next section, “[Local Boot](#).”

3. The first interface on the upstream router to receive the BOOTP request responds.
4. The upstream router calculates the IP address of the AN/ANH’s synchronous interface.

How the upstream router calculates the IP address depends on its protocol configuration. See Step a if the upstream router circuit is running Bay Networks Standard or is a Frame Relay permanent virtual circuit (PVC) in direct access mode. See Step b if it is a Frame Relay PVC in group access mode.

- a. A PVC in direct access mode or a Bay Networks Standard interface calculates the IP address by adding 1 to the IP address of the interface that received the request.

For example, in Figure 1-1 the upstream router's interface address is 192.32.1.1. This means that the upstream router calculates 192.32.1.2 as the booting router's IP interface.




Figure 1-1. Getting an IP Address from a Bay Networks Standard Circuit or a Frame Relay PVC in Direct Access Mode



Note: *If the IP address plus 1 equals a broadcast address, the upstream router calculates the IP address by subtracting 1. For example, if its interface is 7.255.255.254, the IP interface for the booting router is 7.255.255.253.*

- b. A PVC in group access mode references its BOOTP client interface table to find an associated IP address for the booting router.



Note: The BOOTP client interface table contains a data link connection identifier (DLCI) and IP address pair for each PVC. You use Site Manager to create this table when you follow the instructions for setting up routing paths in [Chapter 4](#).

For example, in Figure 1-2, an AN router sends BOOTP requests for its IP address. The upstream router receives the request on PVC 31. The upstream router determines the DLCI, refers to DLCI 31 in the BOOTP client interface table, finds the IP address, and sends a BOOTP response containing the IP address back to PVC 31.




Figure 1-2. Getting an Address from a PVC in Group Access Mode

5. The upstream router sends the IP address and subnet mask to the AN in a BOOTP response message.
6. The AN/ANH assigns the IP address and subnet mask to any synchronous interface that receives a BOOTP response.

7. The AN/ANH stores these addresses, along with the address of the next-hop router, in random-access memory (RAM).

If both synchronous interfaces receive BOOTP responses, the AN/ANH assigns the respective IP addresses to each interface.

Getting Kernel Image and Configuration Files

With a known IP address, the AN/ANH can get image and configuration files.

1. The AN/ANH sends a BOOTP request for the pathnames of a configuration file and image kernel.

The router issues the request simultaneously through all synchronous and Ethernet interfaces that have IP addresses. It issues this request periodically for about 3 minutes, regardless of whether a cable is connected.

2. A BOOTP server responds to the router's request with the directory pathnames ([Figure 1-3](#)).




Figure 1-3. Getting the Pathnames of the Kernel and Configuration Files

The first server interface that processes the BOOTP response acts as the TFTP client in the remaining steps.

3. The AN/ANH stops sending BOOTP requests.
4. The AN/ANH sends a TFTP request for the configuration file.
5. The BOOTP server uses TFTP to transfer the configuration file ([Figure 1-4](#)).




Figure 1-4. Getting the Configuration File

6. The AN/ANH sends a TFTP request for the image kernel file.
7. The BOOTP server uses TFTP to transfer the image kernel file ([Figure 1-5](#)).




Figure 1-5. Getting the Kernel

8. The AN/ANH boots the kernel.
9. The AN/ANH uses TFTP to get application and string files as it needs them.
10. The router begins bridging and routing network traffic in accordance with the configuration file.

The AN/ANH can continue to request files, even after it begins bridging and routing traffic.

If a failure occurs in Steps 1 through 8, the router attempts to boot locally.

Local Boot

When the AN or ANH boots locally, it reads the kernel file, application files, and string files that are embedded within a local software image file (*an.exe*).

When you use Local Boot as the initial boot option, you boot a default (generic) configuration file. You must then complete the “Quick-Start” installation script to customize the default configuration file.

To run the Quick-Start script, you must establish an IP network interface between the AN/ANH and a Site Manager management workstation ([Figure 1-6](#)). To make this connection, you use a Technician Interface command.




Figure 1-6. Establishing an IP Network Interface

Configuring the Initial IP Interface

[Appendix B](#) briefly describes the Quick-Start procedure, provides worksheets for preparing to run the procedure for an AN/ANH, and explains how to begin the Quick-Start script.

Chapter 2

Selecting the Boot Configuration

This chapter provides information to help you select the boot method for both the initial startup of the AN/ANH and for day-to-day startup operations.



Note: To learn about the boot process and startup options, see [Chapter 1](#).

First, refer to one of the following sections for help selecting the startup option:

- [“Booting the Router for the First Time”](#)
- [“Booting the Router Routinely”](#)

Then refer to the section, [“Completing a Startup Option,”](#) for a summary of your steps.

Booting the Router for the First Time

You coordinate the initial startup with a person at the AN/ANH site, who physically installs and cables the router and initiates the desired startup procedure. The hardware installation manual (*Installing and Starting BayStack AN Routers* or *Installing and Starting 8-Port BayStack ANH Systems*) explains these tasks in detail.

After you select the initial startup configuration and set up the network (as described in this guide), you instruct the person at the router site to begin the appropriate startup option.



Note: *As an alternative to another person performing the initial startup at the remote site, you can perform these tasks using a modem connection.*

EZ-Install

You can use EZ-Install for the initial startup if

- There is a communications link between the AN/ANH and an upstream router over an HDLC or Frame Relay interface.
- A directory on a BOOTP server contains a customized configuration file for the AN/ANH.

EZ-Install is the default option for a new router. It is the easiest option for the person at the AN/ANH site to perform, because the network automatically supplies the IP address and configuration file.

Netboot

You can use Netboot if

- The AN/ANH has a communications link to an upstream router over an Ethernet, HDLC, or Frame Relay interface.
- You establish a local console or modem connection with the AN/ANH.
- A directory on a BOOTP server contains the software image file (*krnl_an.exe*) and a network configuration file customized for the AN/ANH.
- You configure an IP address for the AN/ANH boot interface.

Netboot takes longer than EZ-Install, but minimizes the cost of line usage and the saturation of the router's memory.

Local Boot

You can use Local Boot if the AN/ANH has the *an.exe* image on its local file system.

When you use Local Boot as the initial boot option, the router boots a default (generic) configuration file. You must then complete the “Quick-Start” installation script to customize the default configuration file and save it locally.

Refer to the information about the Quick-Start procedure and associated worksheets in [Appendix B](#).

Recommendations

Even if you choose EZ-Install, we strongly recommend that you connect a modem or a console to the router. With a console connection, you can issue commands to the router and display messages. This is very useful if you have network problems after installing the router.

Booting the Router Routinely

This section compares the Netboot, Directed Netboot, and Local Boot options to help you choose a boot configuration for routine startups.



Note: *You can boot an AN/ANH over the network for some procedures and locally for others, provided you set up the network to support Netboot.*

Netboot

Using Netboot for routine startups allows you to

- Manage software image and configuration files from a remote location by storing them on the BOOTP server.

This option greatly simplifies the management of a number of routers by allowing you to concentrate on keeping the startup files up to date in a single, central location — the BOOTP server.

- Minimize the need to maintain the router's local file system.

When the router gets files from a BOOTP server, it stores the files in memory, not in its file system, reducing the need for frequent file-system compactions. (Refer to *Using Technician Interface Software* or *Managing Routers and BNX Platforms* to learn about compacting a file system.)

- Restore a corrupted file system.

The AN/ANH file system resides on an installed flash card. With Netboot enabled, the router can still boot over the network, if the local files become corrupted. (When the AN/ANH reboots due to a reset or power loss, it automatically boots the configuration file and software image over the network if it cannot find intact files locally.)

- Get application and string files from the BOOTP server as the AN/ANH needs them.

Getting these files individually, rather than getting the entire *an.exe* file, minimizes the cost of line usage and prevents saturation of the router's memory.

A disadvantage to Netboot is that it requires the most time to boot the router.

Directed Netboot

Directed Netboot requires a preconfigured communications link to a TFTP server that contains the AN/ANH boot image and a customized configuration file.

Compared with Netboot, Directed Netboot

- Creates less network traffic
- Is generally faster

Directed Netboot is usually reserved for starting the router after the initial startup because you need to know the exact location of the software image and configuration files. During Directed Netboot, the AN/ANH transfers files from a TFTP server directly, bypassing negotiation with a BOOTP server for the IP address and pathname to the software files.

Local Boot

When you choose the Local Boot option for routine startups, the router reads the IP addresses from the local configuration file and assigns them to the appropriate interfaces.

Local-booting the software image and/or configuration file for routine startups allows you to

- Minimize the time it takes to boot routers.

Typically, local-booting an image takes 2 to 3 minutes. Netbooting an image takes a little longer. For example, over a low-speed WAN or after configuring the router to run numerous protocols, Netbooting an image can take up to 15 or 20 minutes.

It also takes less time to local-boot a configuration file than it does to Netboot one. In most configurations, however, the difference between the two options is only a few seconds.

- Minimize line usage.

Getting files from a BOOTP server during Netboot adds traffic to your network during the booting process.

Recommendations

Bay Networks recommends that you

- Set up the network to support Netboot, even if you plan to use the Local Boot option for the initial configuration and for subsequent restarts.
- Maintain the software image (*an.exe*) on the local file system at all times, in case you want to use Local Boot for either of these routers.

Completing a Startup Option

This section lists the steps required to complete

- EZ-Install
- Netboot
- Directed Netboot
- Local Boot

You can use Netboot for some procedures and Local Boot for others, provided you set up the network to support Netboot.



Note: *To boot an AN/ANH over the network, all other routers in the path to the BOOTP server must be running Router Software Version 7.60 or higher.*

EZ-Install

Completing the EZ-Install option requires the following steps:

1. You use the Configuration Manager in local mode to create a complete configuration file for the AN/ANH. (See [Chapter 4](#) and *Configuring Routers*.)
2. You set up a UNIX workstation on the network to support BOOTP. (See [Chapter 3](#).)
3. You create a BOOTP relay interface table on the upstream router to support automated addressing, and configure all routers between the BOOTP server and the booting router as BOOTP relay agents. (See [Chapter 3](#).)
4. You ensure that there is a network connection from a synchronous interface on the AN/ANH to the upstream router.



Note: *If the AN/ANH will connect to the upstream router using a Frame Relay circuit, be sure the upstream router is running Router Software Version 7.80 or higher.*

5. A person at the AN/ANH site installs and boots the router. (See the hardware *Installing and Starting* guide for the AN or ANH.)

6. The AN/ANH gets a software image from its local file system, an IP address from the upstream router, and the customized configuration file from the BOOTP server. (Described in [Chapter 1](#); no action required.)

If the configuration file meets your network requirements, the AN/ANH starts bridging and routing traffic.

You can use the Site Manager Statistics Manager and Events Manager tools to verify that the router is routing traffic according to the configuration you want. (See *Managing Routers and BNX Platforms*.)

Netboot

Completing the Netboot option requires the following steps:

1. You use the Configuration Manager in local mode to create a complete configuration file for the AN/ANH. (See [Chapter 4](#) and *Configuring Routers*.)
2. You set up a UNIX workstation on the network to support BOOTP. (See [Chapter 3](#).)
3. You use Site Manager to enable BOOTP on each router interface in the path between the AN/ANH and the BOOTP server. (See [Chapter 4](#).)
4. You ensure that there is a network connection from a synchronous or Ethernet interface on the AN/ANH to the upstream router.



Note: *If the AN/ANH will connect to the upstream router using a Frame Relay circuit, be sure the upstream router is running Router Software Version 7.71 or higher.*

5. The person at the AN/ANH site establishes a Technician Interface session, or you establish a session via modem. (See the hardware *Installing and Starting* guide for the AN or ANH.)
6. The person at the AN/ANH console uses the **bconfig** and **ifconfig** commands to configure a synchronous or Ethernet interface. (See [Chapter 5](#) and the hardware *Installing and Starting* guide for the AN or ANH.)
7. You install the *netboot.exe* file in the BOOTP server's file system, and make sure the image and application files reside in the same directory. (See [Chapter 3](#).)

8. The person at the AN/ANH site boots the router. (See the hardware *Installing and Starting* guide for the AN or ANH.)

After the router boots, it gets the software image and configuration file from the BOOTP server.

If the configuration file meets your network requirements, the router starts bridging and routing traffic.

You can use the Site Manager Statistics Manager and Events Manager tools to verify that the router is routing traffic according to the configuration you want. (See *Managing Routers and BNX Platforms*.)

Directed Netboot

Completing the Directed Netboot option requires the following steps:

1. You use the Configuration Manager in local mode to create a complete configuration file for the router. (See [Chapter 4](#) and *Configuring Routers*.)
2. You set up the network to support TFTP. (See [Chapter 3](#).)
3. You ensure that there is a network connection from a synchronous or Ethernet interface on the AN/ANH to the upstream router.



Note: *If the AN/ANH will connect to the upstream router using a Frame Relay circuit, be sure the upstream router is running Router Software Version 8.00 or higher.*

4. The person at the AN/ANH site establishes a Technician Interface session (or you establish a session via modem). (See the hardware *Installing and Starting* guide for the AN or ANH.)
5. The person at the AN/ANH console issues **bconfig** and **ifconfig** commands to configure a synchronous or Ethernet interface for Directed Netboot. (See [Chapter 5](#) if you are using a remote Technician Interface session, or, if at the router site, the hardware *Installing and Starting* guide for the AN or ANH.)
6. You install the *netboot.exe* file in the BOOTP server's file system, and make sure the image and application files reside in the specified directory. (See [Chapter 3](#).)

7. The person at the router site boots the router. (See the hardware *Installing and Starting* guide for the AN or ANH.)

The router boots from a local software image and downloads the configuration file from a TFTP server.

The router starts bridging and routing traffic.

You can use the Site Manager Statistics Manager and Events Manager tools to verify that the router is routing traffic according to the configuration you want. (See *Managing Routers and BNX Platforms*.)

Local Boot

Completing the Local Boot option requires the following steps:

1. You complete the Quick-Start worksheets. (See [Appendix B](#).)
2. Either a person at the remote site (using a local console connection) or you (using a modem connection) establish a Technician Interface session. (See [Chapter 5](#) and the hardware *Installing and Starting* guide for the AN or ANH.)

If you are not at the AN/ANH console, you provide the person at the remote router site with the information necessary to complete the Quick-Start worksheets in the installation manual. (See [Appendix B](#).)

3. The person at the AN/ANH console runs the Quick-Start configuration script (*install.bat*), using the information provided in the worksheets you completed in Step 1. (See [Appendix B](#) and the hardware *Installing and Starting* guide for the AN or ANH.)
4. The Quick-Start script records the responses in a configuration file. (See [Appendix B](#) and the hardware *Installing and Starting* guide for the AN or ANH; no action required.)
5. The person at the AN/ANH console reboots the AN/ANH. (See [Chapter 5](#) and the hardware *Installing and Starting* guide for the AN or ANH.)

The router starts bridging and routing traffic.

You can use the Site Manager Statistics Manager and Events Manager tools to verify that the router is routing traffic according to the configuration you want. (See *Managing Routers and BNX Platforms*.)

Chapter 3

Setting Up a UNIX Boot Server

To support network booting, you need to set up a UNIX workstation on the network to run Boot Protocol (BOOTP) and Trivial File Transfer Protocol (TFTP). This chapter describes what you need to do at a UNIX workstation to prepare for booting an AN/ANH over the network.

When a router boots over the network, it gets its startup files from a UNIX server. When the AN/ANH uses EZ-Install or Netboot, the server supplies configuration file and/or software image file pathnames using BOOTP. The AN/ANH then retrieves the files using Trivial File Transfer Protocol (TFTP). When the AN/ANH uses Directed Netboot, it already knows the pathnames of the files it needs and retrieves the files directly from the server using TFTP.

To Configure This Boot Method	Complete These Sections
EZ-Install	“Setting Up a BOOTP Server” and “Setting Up a TFTP Server”
Netboot	“Setting Up a BOOTP Server” and “Setting Up a TFTP Server”
Directed Netboot	“Setting Up a TFTP Server”

Setting Up a BOOTP Server

To support EZ-Install or Netboot, an AN/ANH needs a network connection to a BOOTP server. You configure a UNIX workstation as a BOOTP server by

- Setting up BOOTP sockets
- Configuring *BOOTPD* (the BOOTP daemon)



Note: *A daemon is an unattended process (that is, one that runs in the background). An application typically calls up a daemon to perform a standard routine or service (in this case, BOOTP).*

On Sun workstations, you must first copy the BOOTPD program to the appropriate directory.

Copying the BOOTPD Program on Sun Workstations

Depending on the operating system you use, Bay Networks may or may not ship BOOTPD with the Site Manager package. The AIX and HP-UX operating systems already have BOOTPD. SunOS and Solaris do not, so Site Manager automatically installs BOOTPD on Sun workstations running SunOS and Solaris.

Copy the *bootpd* file to the */etc* directory as follows:

1. **Log in to the UNIX workstation as *root*.**
2. **Enter the following command:**

```
cp /usr/wf/bin/bootpd /etc
```

Setting Up BOOTP Sockets

A *socket* is a UNIX mechanism for creating virtual connections between operating system and network processes. For each socket, the */etc/services* file must include a user datagram protocol (UDP) descriptor that provides process-to-process addressing information.

Set up the send and receive sockets for the BOOTP process as follows:

1. **Log in to the UNIX workstation as *root*.**
2. **Use a text editor to insert the following two lines into the */etc/services* file:**

bootps	67/udp	# bootp server
bootpc	68/udp	# bootp client

Setting Up BOOTPD to Run

Configure your workstation to run the BOOTPD program when it receives a BOOTP request packet, as follows:

1. **As root, use a text editor to open the `/etc/inetd.conf` file.**
2. **Make sure that no other line in the file begins with “bootps.”**

If there is such a line, your workstation is already configured as a BOOTP server. Comment out this line by entering a pound sign (#) at the beginning of the line, so that the server will use the BOOTPD program that you specify in the next step.

3. **Insert the following line anywhere in the file to configure your workstation as a BOOTP server:**

```
bootps dgram udp wait root /etc/bootpd bootpd
```

4. **Save and exit the file.**

Setting Up BOOTPD to Respond to Routers

When the operating system receives a BOOTP packet, it starts up BOOTPD. The BOOTPD software matches the source IP address of the packet to an IP address in its BOOTP table (*bootptab*) file to determine the pathnames to configuration and boot image files.



Note: *The bootptab file can include the same boot image pathname for all booting routers, or a different boot image for each IP address.*

Entries in *bootptab* also include optional parameter tags. Bay Networks supplies a sample *bootptab* file that Site Manager installs automatically in the `/usr/wf/config` directory. Use a copy of this sample file if you do not already have a *bootptab* file.

Set up BOOTPD to respond to booting routers, as follows:

1. **As root, view the contents of the `/etc` directory to determine whether it already contains a *bootptab* file.**

If it does contain a *bootptab* file, disregard Steps 2 and 3 and continue with Step 4 to edit this file.

2. **Issue the following command to copy the *bootptab* file to the */etc* directory:**
`cp /usr/wf/config/bootptab /etc`
3. **Use an editor to open the *bootptab* file in the */etc* directory.**
4. **Type the information that pertains to the ANs and ANHs in your network into the *bootptab* file.**

The section that follows explains how to format your entries. Use Tables [3-1](#) and [3-2](#) to determine which tags and values you need. Figure 3-1 shows the sample *bootptab* file included with the Site Manager software. The comments in this file explain the sample definitions.

5. **After editing the *bootptab* file, be sure to save the changes.**



Note: Be sure the *bootptab* file resides in the */etc* directory. BOOTPD fails if it cannot find the *bootptab* file in */etc*.

Editing the bootptab File

Enter a *<hostname>* definition in the *bootptab* file for each AN/ANH in your network. The format of each definition in the *bootptab* file is as follows:

```
<hostname>:\n: <tg>=<value>:\n: <tg>=<value>:\n: <tg>=<value>:
```

- *<hostname>* is a name you assign to a BOOTP client (each router is a client).
- *<tg>* is a BOOTP parameter name (tag).
- Follow each tag with an equal sign (=) and a value.
- A pound sign (#) at the beginning of a line indicates a comment.
- A backslash (\) at the end of a line indicates continuation of the line.



Note: Make sure you enter a backslash (\), not a slash (/), at the end of every line that does not conclude a definition.

Keep the following in mind when editing *bootptab*:

- The *<hostname>* definition can contain a maximum of 79 characters.
- The first character must be alphabetic.
- All characters must be alphanumeric.
- You can use a dot (.) to separate characters, but the character immediately following the dot must be alphabetic.
- The hostname definition cannot contain an underscore.

[Table 3-1](#) lists the tags for router host names. [Table 3-2](#) lists the tags for boot image names.

Table 3-1. BOOTPD Tags for a Router Host Name

Tag	Required or Optional	Value	Example
ip	Required	IP address — the host IP address of the router.	ip=192.32.5.2
sm	Optional	Subnet mask — the host subnet mask of the router.	sm=255.255.255.0
T129	Required	Pathname of the router configuration file. The maximum path length is 49 characters.	T129="/usr/cfg/an_Bost.cfg"
T130	Required	Size of the router configuration file in 512-byte blocks. The setting of this tag determines how much memory the router allocates for the file. Set this tag to 0x0004.	T130=0x0004
tc	Optional	Table continuation — pointer to a definition in another location in the same file for additional information. The information this tag points to is common to all routers that need to boot using BOOTP. If information in a definition for a specific router is inconsistent with the definition this tag points to, BOOTPD uses the information for the specific router.	tc=general

Table 3-2. BOOTPD Tags for a Boot Image Name

Tag	Required or Optional	Value	Example
hd	Required	Home directory — the directory on the workstation containing the boot files. By default, the Image Builder writes its files to the directory specified in the example. The <code>rel...</code> number is the version number of the current router software release. If you change the default or move the files to another directory, specify that directory.	<code>hd=\$HOME/.builder_dir/rel812/an</code>
bf	Required	Boot file — the name of the boot image.	<code>bf=krnl_an.exe</code>
bs	Required	Boot size — the size of the boot file in 512-octet blocks. If you specify auto as the size, the BOOTP server calculates the size of the file for each BOOTP request.	<code>bs=auto</code>
vm	Required	Vendor magic cookie selector — the BOOTP server should always reply in a manner compliant with RFC 1048. You must enter rfc1048 for this tag, so that the router can understand the BOOTP responses it receives.	<code>vm=rfc1048</code>

The sample *bootptab* file in Figure 3-1 enables two ANs (named “AN.Boston” and “AN.Chicago”) to boot across the network. Use the basic format shown in Figure 3-1 to set up your own *bootptab* file.

```
# This file contains the default specification for the boot
# image file to be used by all ANs.

# "general" contains information that is common to all ANs
# that need to boot via BOOTP. You can use any word in place
# of "general."
    general:\

# "hd" specifies that /$HOME/.builder_dir/rel9000/an is the
# directory on the workstation where the boot files are
# located. By default, the Image Builder writes its files to
# this directory. If you are using a router software version
# later than 8.00, add the associated three digits to the end
# of the "rel" directory name. If you moved the files to
# another directory, specify that directory.
    :hd=/$HOME/.builder_dir/rel812/an:\

# "bf" specifies that the name of the boot image kernel file
# is krnl_an.exe.
    :bf=krnl_an.exe:\

# "bs" indicates the size of the boot file. If you specify
# "auto" as the size, the BOOTP server calculates the size of
# the file for each BOOTP request.
    :bs=auto:\

# "vm" indicates that the BOOTP server should always reply in
# a manner compliant with RFC 1048. You must enter rfc1048
# for this tag so that the AN can understand the BOOTP
# responses it receives.
    :vm=rfc1048:

# This line marks the beginning of the active definition for
# the AN we are naming "AN.Boston."
    AN.Boston:\

# "ip" indicates the IP address of the AN.
    :ip=192.32.5.2:\

# "T130" indicates the size of the AN's configuration file in
# 512-byte blocks. Always use 0x0004.
    :T130=0x0004:\
# "T129" indicates the pathname of the configuration file
# for the AN.
    :T129="/usr1/cfg/AN_Bost.cfg":\

# "tc" indicates that the "general" definition contains more
# information that applies to BOOTP transmissions to
# "AN.Boston."
    :tc=general:

# This is the active definition for the AN we are naming
# "AN.Chicago."
    AN.Chicago:\
    :ip=10.0.0.4:\
    :T130=0x0004:\
    :T129="/rte3/cfg/AN_Chic.cfg":\
    :tc=general:
```

Figure 3-1. Sample bootptab File

Verifying Consistent BOOTP Service

You may want to configure a second workstation as a BOOTP server for backup purposes. If you do so, make sure the two *bootptab* files match exactly. Also, make sure that the image and string files are from the same software version.

Setting Up a TFTP Server

An AN/ANH needs a network connection to a TFTP server to complete EZ-Install, Netboot, or Directed Netboot. You configure a UNIX workstation as a TFTP server by

- Setting up *TFTPD* (the TFTP daemon)
- Adding a TFTP user (for an HP 9000 only)
- Setting up static routes to routers (optional)
- Loading the changes into memory



Note: *A daemon is an unattended process (that is, one that runs in the background). An application typically calls up a daemon to perform a standard routine or service (in this case, TFTP).*

When you set up the *TFTPD* server on a UNIX workstation, you can allow TFTP to access the root directory and any subdirectory or restrict its access to a specified directory or pathname.

Allowing the router to access the root directory and any subdirectory is the simpler procedure. Specifying a pathname provides security, but it requires linking *TFTPD*.

Providing TFTPD Access to the Root Directory

To provide *TFTPD* access to files in the *root* directory and to all subdirectories, verify or insert the appropriate line for your operating system in the */etc/inetd.conf* file.

Find the sample line for your operating system in [Table 3-3](#).

Table 3-3. Providing TFTP Access to Root and All Subdirectories

Operating System (OS)	Sample Line to Insert in <i>/etc/inetd.conf</i> Directory
SunOS	<code>tftp dgram udp wait root /usr/etc/in.tftpd in.tftpd -s /</code>
Solaris	<code>tftp dgram udp wait root /usr/sbin/in.tftpd in.tftpd -s /</code>
HP-UX	<code>tftp dgram udp wait root /etc/tftp tftp</code>
AIX	Use the System Management Interface Tool (SMIT) to configure TFTP. For instructions, refer to the IBM guides on TCP/IP daemons and the TFTP protocol.

Restricting TFTP Access to a Specified Directory

To restrict TFTP file access to a specific directory, insert the appropriate line for your operating system in the */etc/inetd.conf* file.

The examples in [Table 3-4](#) restrict access to the */tftpboot* directory. You can substitute any directory you want.

Table 3-4. Restricting TFTP Access to One Directory

OS	Sample Line to Insert in <i>/etc/inetd.conf</i> Directory
SunOS	<code>tftp dgram udp wait root /usr/etc/in.tftpd in.tftpd -s /tftpboot</code>
Solaris	<code>tftp dgram udp wait root /usr/sbin/in.tftpd in.tftpd -s /tftpboot</code>
HP-UX	<code>tftp dgram udp wait root /etc/tftp tftp -s /tftpboot</code>
AIX	Use the System Management Interface Tool (SMIT) to configure TFTP. For instructions, refer to the IBM guides on TCP/IP daemons and the TFTP protocol.

You must create a symbolic link for every pathname you specify. For example, to set up the symbolic links for the */tftpboot* path, use the following procedure:

1. **Log in to your UNIX workstation as *root*.**
2. **Enter the following commands:**

```
cd tftpboot
ln -s . usr
ln -s . tftpboot
```



Caution: Do not insert a slash (/) in the `cd tftpboot` command; a symbolic link cannot contain references to directories above the directory specified in the `tftpd` command line. Use the **-s** flag to provide additional security to your network. (This flag restricts TFTP access to a specified directory.)

Adding a TFTP User for an HP 9000

Follow the instructions in this section only if you are using an HP 9000 as the Site Manager workstation.

To add a TFTP user for the HP 9000, enter a line with the following syntax in your `/etc/passwd` file. We recommend that you use `root (/)` as the TFTP home directory.

```
tftp: :<user_id>:<group_no.>: :/bin/false
```

For example:

```
tftp: :510:20: :/bin/false
```



Note: We recommend that you not use the *System Administration Manager (SAM)* utility as an alternative to entering the commands above.

Setting Up Static Routes to Next-Hop Routers

If your workstation requires static routes, use this section to specify a path to the network by

- Editing the `inetd.conf` file
- Verifying the routes
- Loading the changes into memory

You must set up a static route for each path between the routers and the BOOTP server's next-hop router.

You may want to specify a static route in a multihop environment or in an environment using routing protocols such as RIP, where minor routing update delays may extend the time it takes to Netboot.

Editing the `inetd.conf` File

Add the following line to the `inetd.conf` file to set up a static route:

route add *<destination>* *<gateway>* *<hops>*

<destination> is the IP address of the AN/ANH or its network.

<gateway> is the IP address of the network destination to which packets are to be addressed.

<hops> is the number of hops to the network destination.

Verifying the Routes

After adding a static route for each path to the booting routers, enter the following command to display the routing table and verify the route you added:

netstat -r

Loading the Changes into Memory

Once you modify the `inetd.conf` file, you must force the operating system to reread it by rebooting the workstation or by issuing a hang-up signal.

In most cases, reboot the workstation. Issue a hang-up signal if the workstation is performing a task that you do not want to interrupt.

Rebooting

Reboot your workstation as follows:

1. **Log in as *root*.**
2. **Execute the following command:**

/etc/shutdown now -r

The **-r** flag reboots the workstation.

Issuing a Hang-Up Signal

Issue a hang-up signal as follows:

1. **Log in as *root*.**
2. **Execute the following command to hang up on the *inetd* process:**

`ps -aux | grep inetd`

The system displays a line similar to this one:

```
root    148  0.0  0.0   48   0 ?    IW Sept 14  0:07 inetd
```

3. **Execute the following command, using the first number in the line after the word “root” (in this case, 148):**

`kill -1 148`

The *inetd* process rereads the *inetd.conf* file.

What to Do Next

Before you can use the network to boot a remote AN or ANH, you must also complete the steps in Chapter 4.

Chapter 4

Configuring Network Booting

This chapter describes how to use Site Manager to configure network booting for AN/ANH routers in the network.



Note: *Before the router can get files over the network, you must also set up a UNIX server on the network, as described in Chapter 3.*

The following sections of this chapter explain how to complete the tasks required for configuring EZ-Install, Netboot, or Directed Netboot.

To Configure This Boot Method	Complete These Sections
EZ-Install	“Preparing Configuration and Image Files”
EZ-Install over Frame Relay group-access PVC	“Preparing Configuration and Image Files” and “Creating the BOOTP Client Interface Table”
Netboot	“Enabling Netboot or Directed Netboot,” “Configuring a Netboot or Directed Netboot Interface,” and “Setting Up Routing Paths for Netboot”
Directed Netboot	“Enabling Netboot or Directed Netboot” and “Configuring a Netboot or Directed Netboot Interface”



Note: *The steps in this chapter assume that the Site Manager software is running on a network workstation.*

Preparing Configuration and Image Files

Unless the AN/ANH will use the default (generic) configuration file and software image that ships on its local Flash memory card, you must create

- A unique configuration file for each remote router
- A uniform software image that all routers in your network can use

Creating Configuration Files

Prepare network configuration files as follows.

1. **Use the Configuration Manager in local mode to create a configuration file for each AN/ANH.**

Refer to *Configuring Routers* for instructions.

2. **Record the name of each configuration file and corresponding AN/ANH for later reference.**

When you name configuration files, keep the following restrictions in mind:

- Configuration files that you save on a BOOTP server do *not* have to be named *config*.
 - Configuration filenames must begin with an alphabetical character. The remaining characters must be alphanumeric and may also include the underscore (_) character. You cannot use spaces.
 - Configuration filenames can consist of 1 to 15 characters (including a dot [.]). We recommend that you limit filenames to eight characters to ensure that all operating systems Bay Networks supports can recognize the names.
 - Configuration filename extensions are optional and must follow a filename and a dot. We recommend that you limit filename extensions to three characters.
 - BOOTP allows a maximum number of 49 characters in a path, including slashes, filename, optional dot, and filename extension.
3. **If the BOOTP server and Site Manager do not reside on the same workstation, transfer the configuration files to the BOOTP server.**

Preparing an Image

If you want the AN/ANH to automatically boot a network image when starting up (using EZ-Install, Netboot, or Directed Netboot), use the Site Manager Image Builder to configure the router to obtain its image from the network rather than locally.

To use Image Builder, perform these steps:

1. **On the Site Manager workstation, open the software image file in the Image Builder.**

Keep the following in mind:

- Be sure to select the correct image (*an.exe*). If you select an image for another router type, you cannot generate the correct files.
- If you configure the router to obtain its image from the network, it cannot Netboot the image until the kernel image is available on the BOOTP server.
- Make sure that you extract the kernel image and all of the application (.exe) files and string (.str) files in the router directory. The files must be from the same software image file whose components were created from the same version of software. If these files are from different software versions, the router may fail to boot or may not operate properly.

Refer to *Modifying Software Images for Routers* for more instructions.

2. **After you open the image file, the Image Builder automatically generates the kernel image, application files, and AN/ANH string files.**

By default, the Image Builder stores these files in `/$HOME/.builder_dir/rel<rel>/an` (where `<rel>` is the current router software release for the router). For example, Version 2.12 of the Site Manager Image Builder tool stores Version 8.12 files for an AN or ANH in the `/$HOME/.builder_dir/rel812/an` directory.

For additional instructions on how to use the Image Builder, refer to *Modifying Software Images for Routers*.

3. **If you use a different workstation as a BOOTP server, transfer all of the files in the directory that contains the kernel file to the new workstation.**

Enabling Netboot or Directed Netboot

By default, the router obtains its software image from its local file system and its configuration file from a BOOTP server. Display and change these settings as follows:

1. **Select Protocols→Global Protocols→Net Boot→Global from the Configuration Manager window.**

The Edit Netboot Global Parameters window appears ([Figure 4-1](#)).




Figure 4-1. Edit Netboot Global Parameters Window

2. **To enable Netboot, set one or both of the first two parameters to “Enable.”**
3. **To enable Directed Netboot, set one or both of the first two parameters to “Enable” and configure the last three parameters.**

For guidelines, see the descriptions of the parameters that follow this procedure.

4. **After editing the parameters, click on OK.**



Note: *Of the five parameter fields shown in [Figure 4-1](#), the first two (Boot Image From Network and Boot Config From Network) apply to both Netboot and Directed Netboot. The last three parameters are for Directed Netboot only.*

Netboot and Directed Netboot Parameters

Parameter: **Boot Image From Network**

Default: Disable

Options: Enable | Disable

Function: Enables or disables retrieval of the software image from the BOOTP server the next time the router starts up.

Instructions: Set to Disable if you want to boot using the image in the router's local file system. This setting reduces the time it takes to boot the router and eliminates using network resources to obtain the image.

Set to Enable if

- You want the router to obtain the image from a BOOTP server and you have already set up the network to support BOOTP service.
- You are upgrading the image on a number of routers. The routers can then boot using a single image on the BOOTP server. You must ensure that the directory name in the *bootptab* file matches the location of the upgraded image before you boot the routers.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.1.1



Note: *As an alternative to enabling the Boot Image From Network parameter, you can use the Router Files Manager to transfer an upgraded image to the AN/ANH. To do this, delete the old software image file, compact the file system, and copy the upgraded image file to the AN/ANH. Use the Router Files Manager to confirm that the upgraded image on the router is the same size as that on the Site Manager workstation. This verifies that the file transfer was successful. Refer to Managing Routers for more information on the Router Files Manager.*

Parameter: Boot Config From Network

Default: Enable

Options: Enable | Disable

Function: Enables or disables retrieval of the configuration file from a BOOTP server the next time the router starts up.

Instructions: Set to Disable if you have already saved the configuration file in the router's memory to the router's file system, and you want to boot using this configuration file. This setting reduces the time it takes to boot the router and eliminates using network resources to obtain the configuration file.

Set to Enable if you want the router to obtain the configuration file from a BOOTP server and you have already set up the network to support BOOTP service.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.1.2

Parameter: Boot Server Address

Default: None

Options: A valid IP address of a TFTP server

Function: When one or both of the parameters Boot Image From Network and Boot Config From Network are set to Enable, this parameter specifies the TFTP server from which the router will obtain the boot image and boot configuration files.

Instructions: Use this parameter only when configuring Directed Netboot. Enter the valid IP address of the TFTP server, in dotted decimal notation.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.1.3

Parameter: Boot Image Pathname

Default: None

Options: A valid image file pathname

Function: When the parameter Boot Image From Network is set to Enable, this parameter specifies the absolute pathname of the boot image file on the TFTP server.

Instructions: Use this parameter only when configuring Directed Netboot. Make sure the file you specify is the valid image file on the TFTP server.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.1.4



Note: *When you netboot a router, the active image parameter shows the full path to the active image on the remote server. When you boot an AN/ANH locally, the name of the active image (wfHwEntry.wfHwActiveImageName) appears in the form <volume>:<image name>.*

Parameter: Boot Config Pathname

Default: None

Options: A valid configuration file pathname

Function: When the parameter Boot Config From Network is set to Enable, this parameter specifies the absolute pathname of the boot configuration file on the TFTP server.

Instructions: Use this parameter only when configuring Directed Netboot. Make sure the file you specify is the valid configuration file on the TFTP server.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.1.5

Configuring a Netboot or Directed Netboot Interface

When you enable Netboot or Directed Netboot, you must configure at least one AN/ANH circuit as a Netboot interface. If you are using EZ-Install, you do not need to configure Netboot interfaces.

Follow these instructions to add a Netboot interface.

1. **Select Protocols→Global Protocols→Net Boot→Interfaces from the Configuration Manager window.**

The Netboot Interfaces window appears ([Figure 4-2](#)).




Figure 4-2. Netboot Interfaces Window

The scroll box is empty unless this router has existing Netboot interfaces configured.

2. **Click on Add.**

The Netboot Interface window appears ([Figure 4-3](#)).




Figure 4-3. AN/ANH Netboot Interface Window

3. Specify the interface's slot number and connector.

For guidelines, see the parameter descriptions that follow this procedure.

4. Click on OK.

The Netboot Interfaces window now shows the configured interface ([Figure 4-4](#)).




Figure 4-4. Netboot Interfaces Window

5. **Highlight the interface in the scroll box and edit its parameters.**

For guidelines, see the parameter descriptions that follow this procedure.

6. **Click on Apply.**
7. **Add any additional Netboot interfaces you want to configure.**
Repeat Steps [2](#) through [6](#).



Note: *If you configure more than one interface to Netboot, the first interface to receive a reply from the BOOTP server will use Netboot to reach the router.*

8. **Click on Done to exit the Netboot Interfaces window.**

Netboot Interface Parameters

Parameter: Slot Number

Default: 1

Options: 1

Function: Specifies the physical slot in which the hardware module is installed.

Instructions: Be sure that number 1 appears in the Slot Number box. (ANs and ANHs have only one slot.)

MIB Object ID: Not Applicable

Parameter: Connector

Default: None

Options: COM1 | COM2 | COM3 | XCVR1 | XCVR2

Function: Identifies the connector configured as a Netboot interface.

Instructions: Enter the connector name for the Netboot interface.

Enter COM1, COM2, or COM3 if you want to use Netboot over a synchronous interface. Enter XCVR1 or XCVR2 if you want to use Netboot over an Ethernet interface. (Note that COM3 and XCVR2 are valid only with an installed interface upgrade.)

MIB Object ID: Not Applicable

Parameter: Connector IP Address

Default: None

Options: Any valid IP address

Function: Specifies the IP address of this interface.

Instructions: Enter the IP address of this interface in dotted decimal notation.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.3.1.4

Parameter: Connector Subnet Mask

Default: None

Options: Any valid IP subnet mask

Function: Specifies the network and subnetwork portion of the 32-bit IP address of this interface.

The Configuration Manager automatically calculates an appropriate subnet mask, depending on the class of the network to which the interface connects. However, you can change the subnet mask with this parameter.

Instructions: Either accept the assigned subnet mask or enter another subnet mask, in dotted decimal notation.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.3.1.5

Parameter: Connector Next Hop

Default: None

Options: Any valid IP address

Function: Specifies the IP address of the next-hop router connected to this interface. When the router starts up, the next-hop router passes the BOOTP requests and responses that initiate the transfer of the image and/or configuration file between the router and the BOOTP server. If the router and BOOTP server are on the same IP subnet, you do not have to set this parameter.

Instructions: Enter the IP address of the next-hop router connected to the interface you are adding, in dotted decimal notation.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.3.1.6

Parameter: Connector Protocol Mask

Default: Point to Point

Options: Point to Point | Point to Point Internal Clock | Fr Relay Annexd | Fr Relay Annexa | Fr Relay LMI

Function: During the boot process, the router will configure the synchronous interface to the specified protocol.

Instructions: Specify the desired protocol option.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.3.1.7

Parameter: Connector State

Default: Enable

Options: Enable | Disable

Function: Enables or disables Netboot on this interface.

When this parameter is set to Enable, any settings already entered in the other four parameter boxes in the Netboot Interfaces window appear and are noted by Site Manager so that Netboot occurs. If the setting is Disable, Site Manager disregards the other parameters and the router cannot Netboot.

Instructions: If you do not want Site Manager to use the settings on the Netboot Interfaces window, set this parameter to Disable. If you want Site Manager to use any of the other four parameters in the Netboot Interfaces window ([refer to Figure 4-2](#)), you must set this parameter to Enable.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.10.3.1.1

Setting Up Routing Paths for Netboot

You set up the routing paths between the BOOTP server and the routers by

- Enabling each router interface in the paths to the routers
- Creating a BOOTP relay agent forwarding table for each router in the path
- Creating a BOOTP client interface table for the upstream router when the AN/ANH is on a Frame Relay PVC in group access mode

Enabling Router Interfaces

You must enable BOOTP relay (also called BOOTP pass-through or gateway) on all interfaces in the paths between the AN/ANH routers and the BOOTP server. For example, you would enable BOOTP relay on the interfaces indicated in [Figure 4-5](#).




Figure 4-5. Enabling BOOTP in a Sample Network

Enable BOOTP relay on an interface as follows:

1. **Click on the connector in the Configuration Manager window.**
2. **Select Edit Circuit in the Edit Connector window.**
3. **Select Protocols→Add in the Circuit Definition window.**
4. **Select BOOTP in the Select Protocols window and click on OK.**
5. **Select File→Exit to exit the Circuit Definition window.**

Creating BOOTP Relay Agent Forwarding Tables

You must create a BOOTP relay agent forwarding table for every router passing BOOTP traffic between the router and the Site Manager workstation.

The BOOTP relay agent forwarding table allows you to specify the IP interface that receives the incoming BOOTP request packets, and the associated IP interface that forwards them. You can add multiple pairs of incoming and outgoing interfaces to support connections to multiple routers in your network.

To create the BOOTP relay agent forwarding table, begin at the Configuration Manager window and complete the following steps.

1. **Select Protocols→IP→BOOTP→Relay Agent Interface Table in the Configuration Manager window.**

The BOOTP Relay Agent Interface Table window appears ([Figure 4-6](#)). This window lists all IP interfaces on the router.



Figure 4-6. BOOTP Relay Agent Interface Table Window

Click on Help or refer to *Configuring SNMP, BOOTP, DHCP, and RARP Services* for a description of the parameters in the BOOTP Relay Agent Interface Table window.



Note: Be sure the *Timeout Secs.* parameter is set to the default: 0.

2. Click on Forward I/F (interface).

The BOOTP Relay Agent Forwarding Table window appears ([Figure 4-7](#)).




Figure 4-7. BOOTP Relay Agent Forwarding Table Window

3. Click on Add.

The BOOTP Addresses window appears ([Figure 4-8](#)).




Figure 4-8. BOOTP Addresses Window

4. Specify the input IP address and output IP address.

For help, refer to the parameter descriptions that follow this procedure.

5. Click on OK.

The BOOTP Relay Agent Forwarding Table window lists the connector and input IP address on the left, and the connector and output IP address on the right.

If you enter an IP address of an interface that is not configured, ??? appears instead of the connector (for example, ??? 192.32.23.3). If you configure the IP address, Site Manager replaces the ??? with the appropriate connector.

6. Click on Done to exit the window.

BOOTP Relay Agent Interface Parameters

Parameter: Input IP Address

Default: None

Options: Any valid IP address

Function: Specifies the IP interface that receives BOOTP request packets from an external network. This interface must have BOOTP configured on it.

Instructions: Enter the IP address of the interface through which the router will receive BOOTP requests.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.2.1.3

Parameter: Output IP Address

Default: None

Options: Any valid IP address

Function: Specifies the IP interface that forwards BOOTP request packets to an external network.

Instructions: Enter the IP address of the interface through which the router will forward BOOTP requests.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.3.2.1.4

Creating the BOOTP Client Interface Table

The *upstream router* is a booting router's next-hop router. By default, the booting router's synchronous interfaces automatically try to get IP addresses from the upstream router. This is the EZ-Install process.

If the AN/ANH using EZ-Install gets its address from the upstream router, and the upstream router's interface to the AN/ANH is a Frame Relay group access PVC, you must use Site Manager to connect to the upstream router and create a BOOTP client interface table (in addition to a BOOTP relay agent forwarding table).



Note: *You do not need to create a BOOTP client interface table if the Frame Relay PVC is configured to operate in direct access mode, or if the circuit is configured to operate with the Bay Networks Standard (HDLC encapsulation) protocol.*

The BOOTP client interface table allows you to specify and pair the IP address of the AN/ANH with the DLCI of the Frame Relay group access PVC.



Note: *If you are using EZ-Install over Frame Relay to boot an AN, you can have up to 20 PVCs for a single Frame Relay interface on the upstream router. If you have more than 20 PVCs on the interface where EZ-Install is occurring, the EZ-Install process may fail. To ensure that the process does not fail, configure no more than 20 PVCs for a Frame Relay interface.*

For more information about the DLCI and Frame Relay, refer to *Configuring Frame Relay Services*.

To create the BOOTP client interface table, begin at the BOOTP Relay Agent Interface Table window ([refer to Figure 4-6](#)) and proceed as follows:

1. **Click on Client I/F.**

The BOOTP Client Interface Table window appears ([Figure 4-9](#)).




Figure 4-9. BOOTP Client Interface Table Window

2. Click on Add.

The BOOTP Client Interface Address window appears ([Figure 4-10](#)).




Figure 4-10. BOOTP Client Interface Address Window

3. Enter the AN/ANH's IP address and its associated DLCI number.

For help, refer to the parameter descriptions that follow this procedure.

4. Click on OK.

The BOOTP Client Interface Table window now lists the client IP interface and the DLCI number you added.

5. **Click on Done to exit the window.**

BOOTP Client Interface Parameters

Parameter: IP Address

Default: None

Options: Any valid IP address

Function: Specifies the IP address of the AN/ANH that is using EZ-Install. This parameter applies only to a Frame Relay group access PVC connection.

Instructions: Enter the IP address (in dotted decimal notation) of the AN/ANH interface.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.1.1.1.3

Parameter: DLCI Number

Default: None

Range: 16 to 1007

Function: Specifies the identification number of the upstream router's PVC to the AN/ANH. The Frame Relay network uses the DLCI number to direct data flow from the AN/ANH to the upstream router.

Instructions: Enter the number in decimal format. Use the DLCI number assigned by your Frame Relay service provider.

MIB Object ID: 1.3.6.1.4.1.18.3.5.3.8.1.1.1.2

Chapter 5

Configuring an Access Node as a Network Boot Client

To enable an AN or ANH for Netboot or Directed Netboot, you configure one or more router interfaces for network booting. You can do this using a Site Manager remote connection (as described in [Chapter 4](#)) or at the AN/ANH local console using Technician Interface commands. This chapter describes how to use the

- **ifconfig** command to configure the AN/ANH's initial IP interface to the network
- **bconfig** command to specify the location and name of a software image and configuration file

To Configure This Boot Method	Complete These Sections
Netboot or Directed Netboot over a synchronous interface	"Configuring the Router Boot Source" and "Configuring an IP Synchronous Interface for Network Booting"
Netboot or Directed Netboot over an Ethernet interface	"Configuring the Router Boot Source" and "Configuring an Ethernet Interface for Network Booting"

Working with a Person at the AN/ANH Site

Written for a person at the AN/ANH site, the guides *Installing and Starting BayStack AN Routers* and *Installing and Starting 8-Port BayStack ANH Systems* provide instructions for setting up the router for each of the boot options. These instructions assume that a network administrator provides the person at the AN/ANH site with the appropriate **ifconfig** and **bconfig** commands.

This chapter provides instructions for using the **ifconfig** and **bconfig** commands to configure Netboot and Directed Netboot. If you are not configuring the AN/ANH yourself, you can determine the appropriate syntax for these commands and provide the person at the router site with the exact command lines to use.

Configuring the Router Boot Source

To use Netboot, you use the **bconfig** command to specify that the AN/ANH configuration file or software image resides on the network. To use Directed Netboot, you use the **bconfig** command to specify the IP address of the server and the full pathname to the software image and configuration file.

bconfig Command Format

To configure an interface for Netboot, use the following format for the **bconfig** command:

bconfig -d [image|config] network

To configure an interface for Directed Netboot, use the following format:

bconfig [image|config] network [<TFTP host> <TFTP pathname>]

You must use the **bconfig** command twice: once to specify the location of the software image, and again to specify the location of the configuration file.

Refer to [Table 5-1](#) for a complete description of the **bconfig** command.

Table 5-1. bconfig Command Settings

Option	Description
image	Indicates the router's software image.
config	Indicates the router's configuration file.
network	Indicates that the specified file (image or configuration) resides on a remote file system.
<TFTP host>	Specifies the IP address of the TFTP server. If both the software image and configuration file are on the network, both files must reside on the same host.
<TFTP pathname>	Specifies the complete pathname of the remote software image or configuration file.
-d	Reverts to the default values for the software image or configuration file and nullifies any previously specified IP address and pathname for the file, thus disabling Directed Netboot.

bconfig Command Examples

1. Configure the default Netboot procedure — use a local image file and look for the configuration file over the network using BOOTP.

```
bconfig -d image (or bconfig image local)  
bconfig -d config (or bconfig config network)
```

2. Use Netboot for both the boot image and configuration file.

```
bconfig image network  
bconfig config network
```

3. Use a local configuration file and Directed Netboot for the boot image file.

```
bconfig image network 21.3.5.62 /usr/mykernel.exe  
bconfig config local
```

4. Use a local boot image file and Directed Netboot for the configuration file.

```
bconfig image local  
bconfig config network 21.3.5.62 /usr/anstartup/config
```

5. Use Directed Netboot for both the boot image and configuration file.

```
bconfig image network 21.3.5.62 /usr/mykernel.exe  
bconfig config network 21.3.5.62 /usr/anstartup/config
```

Configuring the Netboot Interface

A router interface cannot communicate in an IP network without an IP address. Because an AN/ANH netboots over one of its synchronous or Ethernet links, the Netboot interface must have a valid IP address.

You have two options for assigning an IP address to an interface:

- Use the Technician Interface **ifconfig** command to manually configure a synchronous or Ethernet interface for Netboot or Directed Netboot.
- Configure the upstream router to support automated addressing for EZ-Install.

[Chapter 4](#) describes how to configure the upstream router to support EZ-Install by creating the BOOTP client interface table. “[The Boot Process](#)” section in [Chapter 1](#) describes how the router automatically obtains an IP address during the EZ-Install process.

The following sections describe each use of the **ifconfig** command.

Configuring an IP Synchronous Interface for Network Booting

Configure a synchronous interface to the IP network using the following interface configuration command:

```
ifconfig [synchronous options] <interface> [<IP address> <subnet mask> [<next hop address>]]
```

The *synchronous options* variable indicates some combination of the following settings:

```
[-d | -fr [-annexd | -lmi | -annexa] | -int_clk]
```



Note: Insert a space to separate each command option from the next.

[Table 5-2](#) describes the **ifconfig** command arguments for configuring an AN/ANH synchronous interface.

Table 5-2. ifconfig Command Settings for a Synchronous Interface

Setting	Description
Default Setting	
-d	Resets the router's IP interface settings to the default values. This setting tries four WAN configurations in the following order until it finds the correct type for the router's connection to the network: 1. Bay Networks HDLC encapsulation (also referred to as Bay Networks Standard Point-to-Point) with external clocking 2. Frame Relay Annex D 3. Frame Relay LMI 4. Frame Relay Annex A

(continued)

Table 5-2. ifconfig Command Settings for a Synchronous Interface
(continued)

Setting	Description
Frame Relay Settings	
-fr	Configures the router's synchronous port as a Frame Relay connection. With this setting, use one of the following options to specify a DLCMI setting: -annexd , -annexa , or -lmi .
-annexd -annexa -lmi	When one of these options is used with the -fr setting, it specifies a DLCMI setting. Use the same setting as the network to which the router's Frame Relay interface is connected. The default setting for Frame Relay is -annexd .
Internal Clocking Setting	
-int_clk	Sets the synchronous port to internal clocking at 1.25 MB/s. If you do not specify this setting, the router defaults to external clocking.
IP Connector Setting	
<interface>	Specifies the IP connector you are configuring. Use the format com<port no.> .
IP Address Settings	
<IP address>	Specifies the IP address of the interface you set with <interface> . Provide this address in dotted decimal notation.
<subnet mask>	Specifies the IP subnet mask of the interface you set with <interface> . Provide this address in dotted decimal notation.
<next hop address>	Specifies the IP address of the next-hop router. Provide this address in dotted decimal notation. Specify this address only if there are intermediate routers between the router and the BOOTP server.

Configuring an Ethernet Interface for Network Booting

To configure an AN/ANH Ethernet interface for network booting, use the following command format:

```
ifconfig [-d] <interface> [<IP address> <subnet mask>] [<next hop address>]
```

[Table 5-3](#) describes the **ifconfig** command arguments for configuring the router's Ethernet interface.

Table 5-3. ifconfig Command Settings for an Ethernet Interface

Setting	Description
Default Setting	
-d	Resets the router's IP interface settings to the default values. Resetting an Ethernet interface makes it inactive in the network booting process. (The output of the getcfg command shows the default as None.)
IP Connector Setting	
<i><interface></i>	Specifies the IP connector you are configuring. Use the format xcvr <i><port no.></i> .
IP Address Settings	
<i><IP address></i>	Specifies the IP address of the interface you set with <i><interface></i> . Provide this address in dotted decimal notation.
<i><subnet mask></i>	Specifies the IP subnet mask of the interface you set with <i><interface></i> . Provide this address in dotted decimal notation.
<i><next hop address></i>	Specifies the IP address of the next-hop router. Provide this address in dotted decimal notation. Specify this address only if there are intermediate routers between the router and the BOOTP server.

Enabling and Disabling Interfaces with ifconfig

To enable or disable an AN/ANH interface for the network boot process, use the following command formats:

ifconfig -disable *<interface>*

ifconfig -enable *<interface>*

[Table 5-4](#) describes the **ifconfig** command arguments for enabling and disabling interfaces for network booting.

Table 5-4. ifconfig Settings to Enable and Disable Netboot Interfaces

Setting	Description
<i><interface></i>	Specifies the IP connector you are enabling or disabling for network booting. Use the format: xcvr <i><port no.></i> or com <i><port no.></i>

ifconfig Command Examples

1. Configure the current interface for the default Netboot procedure.
ifconfig -d
2. Specify the IP address and subnet mask of the first Ethernet Netboot interface.
ifconfig xcvr1 21.3.5.62 255.255.255.255
3. Specify the IP address and subnet mask of the second Ethernet Netboot interface.
ifconfig xcvr2 21.3.5.61 255.255.255.255
4. Configure the IP address and Frame Relay DLCMI of the third synchronous Netboot interface.
ifconfig com3 21.3.5.62 -fr -annexa

What to Do Next

You can now boot the AN/ANH over the network, assuming that you already

- Configured a UNIX workstation to support network booting, as described in [Chapter 3](#)
- Prepared configuration and boot image files and placed them in the appropriate locations for your boot configuration, as described in [Chapter 4](#)

Whenever you boot the AN/ANH, it should start routing traffic according to the configuration file it obtains from the BOOTP server.

You use the Site Manager Statistics Manager to view traffic statistics and the Event Log to determine whether the AN/ANH is routing traffic. Refer to *Managing Routers* for instructions on using the Statistics Manager and Events Manager tools.

If the AN/ANH does not begin routing traffic after booting, refer to [Appendix A](#) of this guide.

Chapter 6

Configuring AN and ANH Features

This chapter describes how to configure special features specific to the AN and ANH. It explains how to

- Manage ANH repeater ports.
- Configure and manage a Data Collection Module (DCM) option.

Managing ANH Repeater Ports

You manage ANH repeater ports using Site Manager software. From Site Manager, the ANH repeater ports operate as a single interface, XCVR1. Software configuration parameters such as the port IP address apply to all repeater ports.

Testing and Resetting Repeater Ports

Use the following procedure to reset and test ANH repeater ports.

1. **From the Site Manager window, which appears at Site Manager startup, select Tools→Configuration Manager→Dynamic.**

The Configuration Manager window appears, displaying the real-time router hardware and software configuration.

2. **From the Configuration Manager window, select Platform→Setup Repeater→Group Parameters ([Figure 6-1](#)).**




Figure 6-1. Selecting the Repeater Hub Group Parameters Window

The Group Parameters window appears ([Figure 6-2](#)), allowing you to reset the ANH or issue the self-test command.



Figure 6-2. Group Parameters Window

3. Edit the parameters you want to change, using the parameter descriptions that follow as guidelines.
4. When you are finished, click on OK.

The Configuration Manager executes the action or actions you indicated in the Group Parameters window and closes the window.

Repeater Port Group Parameter Descriptions

Parameter:	Reset
Default:	NO_RESET
Options:	NO_RESET RESET
Function:	Resets the repeater. The Configuration Manager tests each repeater port and records to a log file whether a port passed diagnostics. The reset does not affect the management counters defined in the RFC 1516 MIB nor does it affect the status of the ports. It does disrupt traffic flow.
Instructions:	Accept the default, NO_RESET, or select RESET.
MIB Object ID:	1.3.6.1.2.1.22.1.1.4
Parameter:	Selftest
Default:	NO_SELFTEST
Options:	NO_SELFTEST SELFTEST
Function:	Causes the router to perform an agent-specific test on itself. This test does not disrupt traffic flow.
Instructions:	Accept the default, NO_SELFTEST, or select SELFTEST.
MIB Object ID:	1.3.6.1.2.1.22.1.1.5

Enabling and Disabling ANH Repeater Ports

Use the following procedure to enable or disable the repeater ports on an ANH.

1. **From the Site Manager window, which appears at Site Manager startup, select Tools→Configuration Manager→Dynamic.**

The Configuration Manager window appears, displaying the real-time router hardware and software configuration.

2. **From the Configuration Manager window, select Platform→Setup Repeater→Port Status ([Figure 6-3](#)).**




Figure 6-3. Selecting the Repeater Port Status Window

The Port Status window appears, allowing you to enable or disable the ports on the router.

[Figure 6-4](#) shows the port status window for the 8-port ANH. [Figure 6-5](#) shows the port status window for the 12-port ANH.




Figure 6-4. 8-Port ANH Port Status Window



Note: The ninth port is the AUI interface from the 8-port ANH router to the repeater. To disable the connection, disable the Ethernet circuit on port nine.




Figure 6-5. 12-Port ANH Port Status Window



Note: *The thirteenth port is the Ethernet connection from the router base board to the repeater module. You disable the repeater by disabling Port 13.*

3. To change the status of a port, click on Enabled or Disabled to the right of the port number.
4. When you are finished, click on OK to exit the window and save your changes.

Configuring an N11 Data Collection Module

This section describes how to configure the N11 Data Collection Module (DCM) as an Ethernet remote monitoring (RMON) device. It provides

- Overviews of the N11 DCM and RMON
- Instructions for enabling the N11 DCM
- Instructions for managing the N11 DCM using Site Manager
- Instructions for managing the N11 DCM using the Technician Interface
- RMON implementation notes for operating the N11 DCM



Note: *This section applies only if you have an optional N11 Ethernet Data Collection Module (DCM) installed in a BayStack AN or 8-port ANH.*

About the N11 DCM

The N11 DCM physically connects to the AN or ANH base board. It contains a Flash memory SIMM for its own boot image and configuration file. The DCM runs RMON agent software that

- Gathers statistics by monitoring packets on an Ethernet segment
- Stores the information according to the RMON MIB specification, in compliance with RFC 1757

To communicate with the RMON agent software on the DCM board, the ANH requires a software subsystem, called DCM *middleware* (DCMMW). This software subsystem enables and configures an installed DCM board. Using Site Manager, you use the DCMMW to

- Enable and initially configure the DCM
- Modify the DCM configuration
- Boot the DCM
- Disable the DCM

To set up other RMON configurations and to view RMON statistics, use Optivity Design and Analysis software or a third-party RMON network management application.

About Remote Network Monitoring (RMON)

RFC 1757 is an extension of SNMP. It specifies a standard MIB that defines both parameters for recording statistics and the actual statistics themselves.

The purposes of RMON include

- Monitoring network performance
You can configure the DCM to continuously perform diagnostics and monitor network performance. If a network failure occurs, the DCM can store statistical information about the failure. The management stations can use this information to investigate the cause of the failure.
- Detecting and reporting problems
You can configure the DCM to recognize and continuously check for error conditions.
- Collecting information for problem solving
You can configure the DCM to give management stations information they need to solve problems. For instance, the DCM can identify the hosts on a network that generate the most traffic or errors.

Refer to “[RMON Implementation Notes](#),” later in this chapter, for issues you should consider when using an N11 DCM for RMON.

The RMON Groups

The RMON agent runs on the DCM, and comprises a set of MIB groups. RFC 1757 defines the function and organization of these groups. Bay Networks implements the following groups in its RMON agent:

- Ethernet Statistics
- History Control
- Ethernet History
- Host
- HostTopN
- Matrix
- Filter
- Packet Capture

RMON groups contain *control* and *data tables*. Control tables contain *control parameters* that specify which statistics you want to access. You can view and change many entries in a control table. Data tables contain statistics the agent obtains, and usually you can only view entries in these tables.

Some of the groups work together to provide a particular RMON function. For example, the History Control group and the Ethernet History group together provide the history capability in the RMON agent for the DCM.

The following sections indicate the function of each group and the tables that each group defines. Refer to RFC 1757 for the following information:

- A list of all the parameters that appear in a control table
- The read/write status of a control parameter
- The default values for control parameters with read/write status
- A list of all the objects that appear in a data table

Ethernet Statistics Group

The Ethernet Statistics group records data that the DCM measures on network interfaces. The DCM creates one entry for each Ethernet interface it monitors on a device and places the entry in the EtherStatsTable. The EtherStatsTable also contains control parameters for this group.

History Control Group and Ethernet History Group

The History Control and Ethernet History groups work together to control and record the periodic statistical sampling of data from various types of networks. The historyControlTable and etherHistoryTable comprise the two groups.

Host Group

The Host group identifies hosts on the network by recording the source and destination MAC addresses in good packets, and places the information in the hostTable. This group also records the time it discovered a host on the network in the hostTimeTable. The hostControlTable specifies control parameters and contains information about the monitoring process.

HostTopN Group

The HostTopN group ranks hosts according to a statistic type. For example, you might want to rank the hosts by the number of errors they generate. Control parameters for this group appear in the hostTopNControlTable, and data this group generates appears in the hostTopNTable. To use the HostTopN group, you must set up the Host group.

Matrix Group

The Matrix group stores statistics for an interchange between interfaces at different addresses. This group's control parameters, such as the interface that starts the interchange, appear in the matrixControlTable. When the Matrix group receives information from a good packet, it places data in both the matrixSDTable and the matrixDSTable.

Filter Group

The Filter group specifies what type of packets the DCM should capture. Filter control parameters, such as the minimum length of the packets to capture, appear in the filterTable. Associated with each filter is a *channel* (a specific path along which data flows). Control parameters in the channelTable define how and where the filtered packets flow.

Packet Capture Group

The Packet Capture group enables the capture of packets that satisfy the Filter group control parameters. For example, you can specify the maximum number of octets from each packet that the group should store in the captureBufferTable. To use the Packet Capture group, you must set up the Filter group.

For More Information about RMON

The following documents provide more detail:

- RMON MIB (RFC 1757)
- The user guide for Optivity Design and Analysis network management software

Enabling the DCM

Use the Configuration Manager to enable a newly installed N11 DCM option by creating the DCM software subsystem (DCMMW).

1. From the Configuration Manager window, select **Platform→DCM→Create DCM** ([Figure 6-6](#)).



Figure 6-6. Creating the DCM Software Configuration from the Configuration Manager

The Edit DCM Parameters window appears ([Figure 6-7](#)).




Figure 6-7. Edit DCM Parameters Window

2. To accept the default configuration, click on OK. Or, to customize the configuration, continue with [Step 3](#).
3. Edit the parameters you want to change.
Use the descriptions that follow as guidelines.
4. When you are finished, click on OK.



Caution: Configuration changes are effective only after you reboot the DCM board. To do this, use the Edit DCM Parameters window to disable and then re-enable DCM.

DCM Global Parameter Descriptions

Parameter:	Enable/Disable
Default:	ENABLE
Options:	ENABLE DISABLE
Function:	Enables or disables DCMMW (the DCM software subsystem), and therefore the DCM board.
Instructions:	To enable the DCM board, select ENABLE. To disable the DCM board, select DISABLE. Use this parameter to reboot the DCM board by enabling, then disabling DCMMW.
MIB Object ID:	1.3.6.1.4.1.18.3.3.2.16.1.2

Parameter:	Image Name
Default:	None, but you must specify an image name when the Boot Option parameter is set to DOWNLOAD.
Options:	An ASCII text string, no more than 255 characters
Function:	Specifies the pathname of a DCM boot image in the ANH file system. The image name must be a fully qualified filename, including both volume and filename.
Instructions:	Enter the volume and filename for the image you want the DCM board to boot, using the form <i><volume_number:filename></i> ; for example, 1:dcm_image .
MIB Object ID:	1.3.6.1.4.1.18.3.3.2.16.1.3

Parameter: Boot Option

Default: LOCAL

Options: LOCAL | DOWNLOAD

Function: Specifies whether the DCM board uses the image in its own Flash memory for booting or an image copied from the ANH file system to DCM shared memory (DRAM).

Instructions: Select LOCAL to specify the image file in DCM local Flash memory as the DCM boot image. Select DOWNLOAD to specify an image file on the ANH Flash memory as the DCM boot image. When the DCM board boots in DOWNLOAD mode, DCMMW software moves a copy of the image to DCM shared memory. You specify the downloaded image with the Image Name parameter.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.16.1.4

Parameter: Image Save Mode

Default: SAVE

Options: SAVE | NO SAVE

Function: Specifies whether the DCM saves the active image into its local Flash memory or keeps the image in shared DRAM only.

Instructions: To save the DCM boot image file to the DCM board's local Flash memory (writing over the existing saved image), select SAVE. Select the NO SAVE option if you do not want to save the DCM boot image file (the image remains in DRAM until the next time the DCM board boots).

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.16.1.5

Parameter: Configuration Mode

Default: LOCAL

Options: LOCAL | SHARED MEMORY

Function: Specifies whether to use configuration information in the DCM board Flash memory or in the DCM board's shared memory space (DRAM).

Instructions: Select LOCAL to use the default configuration information in the DCM local Flash memory. Select SHARED MEMORY to use the configuration information in the DCM DRAM, written by DCMMW from the ANH file system.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.16.1.6

Parameter: Write Configuration Info

Default: WRITE

Options: WRITE | NO WRITE

Function: Specifies whether or not to write the configuration information in DRAM to the DCM board's Flash memory.

Instructions: Select WRITE to save the configuration information in DRAM to the DCM board's Flash memory (writing over the existing configuration file). Select NO WRITE to avoid overwriting the DCM board's configuration file.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.16.1.7

Parameter: RMON Max Host

Default: 500

Range: 100 to 8128

Function: Relates to the RMON Host group. Indicates the maximum number of host addresses to be collected in each entry of the RMON host control table. The maximum limit depends on the amount of Flash memory available in the DCM. When the host control table reaches the maximum value, the DCM deletes entries based on an LRU (least recent used) algorithm.

Instructions: Recommended values, based on DCM memory configurations, are
2 to 4 MB: 2048
8 MB: 4096
16 MB: 8128

To verify the number of hosts configured, check the MIB object wfDCMmwRMONHost using the Site Manager Statistics tool.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.16.1.8

Parameter: RMON Default Host

Default: Enable

Options: Enable | Disable

Function: Specifies whether or not to create the RMON Host Control Table at every boot. Some RMON network management applications expect the DCM to set up a host configuration. Others enable and disable their own configurations during normal operations.

Note that the DCM allows only one instance of the host control table.

Instructions: Select Enable to create the RMON Host Control Table at the next (and every subsequent) reboot. Select Disable to disable default creation of the RMON host control table at boot time.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.16.1.9

Parameter: RMON Default Matrix

Default: Enable

Options: Enable | Disable

Function: Relates to the RMON Matrix group. Specifies whether or not to create the RMON Matrix Control Table at every boot. Some RMON network management applications expect the DCM to set up a matrix configuration. Others enable and disable their own configurations during normal operations.

Note that the DCM allows only one instance of the matrix control table.

Instructions: Select Enable to create the RMON Matrix Control Table at the next (and every subsequent) reboot. Select Disable to disable default creation of the RMON Matrix Control Table at boot time.

MIB Object ID: 1.3.6.1.4.1.18.3.3.2.16.1.10

Managing the DCM Using Site Manager

You use Optivity Design and Analysis software or a third-party RMON network management application to set up RMON configurations and to view statistics. To manage the installed DCM, you can use Site Manager to

- Change the DCMMW configuration
- Enable or disable a default RMON Max Host, Default Host, and Default Matrix configuration
- Activate, temporarily disable, and boot the DCM board
- Deactivate the DCM by disabling the DCMMW software subsystem

Activating DCM

1. **From the Configuration Manager window, select Platform→DCM→Global (refer to [Figure 6-8](#)).**

The Edit DCM Parameters window appears (refer to [Figure 6-7](#)).

2. **Set the Enable/Disable parameter to ENABLE.**
3. **Click on OK to exit the Edit DCM Parameters window.**

Disabling DCM

To temporarily disable an installed DCM board:

1. **From the Configuration Manager window, select Platform→DCM→Global (refer to [Figure 6-8](#)).**

The Edit DCM Parameters window appears (refer to [Figure 6-7](#)).

2. **Set the Enable/Disable parameter to DISABLE.**
3. **Click on OK to exit the Edit DCM Parameters window.**

If disabling the board does not work, you can delete the software subsystem to totally shut down the DCM.

Booting DCM

To reboot an installed DCM board, disable and then re-enable the DCM as described in the previous sections.

Changing DCM Configuration Parameters

To edit the DCMMW configuration parameters for an installed DCM board, follow these steps:

- 1. From the Configuration Manager window, select Platform→DCM→Global (Figure 6-8).




Figure 6-8. Selecting the DCM Parameters Window

The Edit DCM Parameters window appears (Figure 6-9).




Figure 6-9. Edit DCM Parameters Window

2. Set the Enable/Disable parameter to **DISABLE**.
3. Click on **OK**.
4. Select **Platform→DCM→Global** again (see [Figure 6-8](#)) to return to the Edit DCM Parameters window.
5. Set the Configuration Mode parameter to **SHARED MEMORY**.
6. To use this configuration in subsequent boots, set the Write Configuration Info parameter to **WRITE**.
7. Set the Enable/Disable parameter to **ENABLE**.
8. Click on **OK**.

Deleting the DCM Software Subsystem

The ANH requires the DCMMW software to communicate with the DCM board. Deleting DCMMW deactivates the DCM board.

 **Note:** Always try *disabling* the DCM board by setting the Enable/Disable parameter to Disable before you delete the DCMMW software.

To completely deactivate the DCM board:

1. From the Configuration Manager window, select Platform→DCM→Delete DCM ([Figure 6-10](#)).




Figure 6-10. Deleting DCM from the Configuration Manager Window

- Configuration Manager displays a confirmation prompt.
2. Click on OK.
- Configuration Manager deletes the DCMMW base record, bringing the DCM board completely down.
- After deleting the DCM configuration, you reactivate the DCM board by selecting Platform→DCM→Create DCM to recreate the DCMMW record (refer to [Figure 6-6](#)).

Managing the DCM Board Using the Technician Interface

You can use Technician Interface commands to

- Enable, disable, and reboot the DCM board (**enable/disable dcmmw** scripts).
- Display or modify DCMMW configuration parameters (**set/get** commands).
- Download a new DCM software image (**dcmload** script).



Caution: *Avoid running scripts that continually issue Technician Interface commands while you are running another RMON network management application. This combination can cause the SNMP agent to fill the system buffers with RMON data, leading to a system restart.*

For more information about using the Technician Interface to access the DCM MIB objects, refer to *Using Technician Interface Software* and *Using Technician Interface Scripts*.

Changing DCM Configuration Parameters

Modifying DCM or RMON parameters by issuing **set** and **commit** commands with the MIB object ID is equivalent to modifying parameters using Site Manager. To change DCM configuration parameters, be sure to set the value of `wfDCMmw.wfDCMmwCfgMode.0` to `DCMMW_CFG_LOAD_SHMEM` before changing other object values. After you change any DCM object values, always reboot by enabling, then disabling the DCM board to initialize the change.

For example, issue the following commands to change the maximum Host configuration:

```
set wfDCMmw.wfDCMmwRMONMaxHost.0 1200;commit  
disable dcmmw base  
enable dcmmw base
```

To use a configuration change in subsequent boots, be sure the `wfDCMmwWriteConfigInfo` parameter is set to `DCMMW_CFG_WRITE` so the DCM saves the new information to its Flash memory.



Caution: *The Technician Interface does not verify that the value you enter for a parameter is valid. Entering an invalid value can corrupt your configuration.*

RMON Implementation Notes

Read the following sections to learn about RMON memory use and interoperability issues you should consider when using RMON network management applications with the DCM. These sections assume that you have a good understanding of each RMON group, and do not refer to the low-level details of the MIB, such as RMON MIB objects. Refer to “[About Remote Network Monitoring \(RMON\)](#),” earlier in this chapter, and RFC 1757 for information about each RMON group.

RMON Interoperability Issues

Some network management applications automatically set up their own configurations for an RMON group, without checking to see if the RMON agent already has a default configuration. In addition, when you terminate those applications, they may not remove the configurations they set up for the RMON agent. These features can result in the RMON agent using excessive amounts of memory and processing power.

Example

When you enable a DCM, the RMON agent automatically creates a History configuration. Suppose you then start a third-party RMON History application, which creates its own History configuration for the agent. The RMON agent stores the data in two places, wasting memory.

In addition, when you terminate the third-party RMON application, it does not remove its History configuration, using memory and processing power indefinitely.

You can release these resources only by using another application, such as the SNMP tool or network management station, or by resetting the DCM. If you use too many resources for an RMON task, the DCM can run out of memory for other RMON tasks and performs more slowly.

RMON Memory Use

The total amount of RMON memory depends on the DRAM in the DCM ([Table 6-1](#)).

Table 6-1. DRAM and RMON Memory Size

Installed DRAM (MB)	RMON Memory in Bytes
2	162,578
4	2,077,330
8	5,222,034
16	12,561,042



NOTE: *If the RMON memory pool is full or if the RMON agent reaches an implementation limit, the agent responds to an SNMP **set** command on an RMON control table entry with an SNMP GEN-ERROR.*

The following sections describes how much memory you need to

- Configure an RMON group (for example, to configure the Matrix group or to configure Filter and Packet Capture groups).
- Store the data for an RMON group (for example, to store the packets a DCM captures).

In the following sections, the word *configuration* means the set of control tables for a group. For example, a Matrix configuration includes only the matrixControlTable. Note that you can create more than one configuration for some RMON groups. For example, you can create more than one History configuration, allowing you to specify different intervals for sampling statistics.

Interoperability Issues and Memory Use for RMON Groups

You should understand the following issues about each RMON group's memory requirements and ability to operate with third-party RMON network management applications.

Statistics Group

When you enable the DCM, the RMON agent automatically creates a Statistics configuration that records data for each network interface.

Through your RMON network management application, you can create as many Statistics configurations as memory permits, up to the RMON limit of 65,535 configurations.

If you create multiple configurations, it is possible to collect the same set of statistics for the same interface in multiple data tables. The absolute values of those statistics may vary from table to table, because the baseline of each statistics counter occurs when you create a configuration. You may prefer, however, to use only one Statistics configuration, to conserve memory for other RMON groups.

You need 200 bytes of memory for each Statistics configuration.

History Group

When you enable the DCM, the RMON agent automatically creates a History configuration that collects History data at two intervals. The first configuration provides short-term history by sampling statistics every 30 seconds and holding up to 50 samples (in RMON terms “buckets”). The second configuration provides long-term history by sampling statistics every 30 minutes and holding up to 50 buckets.

Through your RMON network management application, you can create as many History configurations as memory permits, up to the RMON limit of 65,535 configurations. You can also set the number of buckets a particular History configuration uses to as many as available memory allows. If you request more buckets than memory allows, the agent allocates enough buckets to fill available memory.

You need 504 bytes of memory for each History configuration (252 bytes each for the short-term and long-term History configurations).

The History data requires 52 bytes of memory per bucket. You calculate the total memory (in bytes) you need to store the data as follows:

Number of buckets * 52 * 2 History configurations

This calculation shows that you need approximately 5.1 KB for the default setting of 50 buckets.

Host Group

When you enable the DCM, the default setting (Enabled) for the RMON Default Host parameter creates a Host configuration. To prevent creation of a Host configuration, set the RMON Default Host parameter to Disabled before you enable the DCM as described in the “[Activating DCM](#)” section.

Some RMON network management applications expect the DCM to set up a Host configuration, while others set up their own configurations.



NOTE: *The RMON agent allows you to create only one Host configuration. Be sure to set the RMON Default Host parameter according to the expectations of the RMON network management application.*

The Host configuration requires 148 bytes. The Host data requires 105 bytes of memory per host address the DCM detects on a segment.

You specify the maximum number of host addresses that appear in the Host configuration by setting the RMON Max Host parameter when you enable a DCM. If there is not enough memory for the number of hosts you request, the RMON agent sets the RMON Max Host parameter to the highest possible value. The number of addresses can range from 100 to 8,128, depending on the DCM memory configuration. [Table 6-2](#) shows recommended values for this parameter.

Table 6-2. Maximum Number of Hosts

Installed DRAM (MB)	Maximum Number of Hosts
2–4	2,048
5–8	4,096
9–16	8,128

You calculate the total memory (in bytes) you need for the host data as follows:

105 * Value of the RMON Max Host parameter

HostTopN Group

To save memory and increase performance, there is no default configuration for the HostTopN group. You must create HostTopN configurations through your RMON network management application. You can create as many HostTopN configurations as memory permits, up to the RMON limit of 65,535 configurations.



NOTE: *Before you create a HostTopN configuration, you must create a Host configuration.*

Each HostTopN configuration requires 164 bytes. The HostTopN data requires 10 bytes of memory per host address the DCM detects on a segment.

You calculate the total memory (in bytes) you need for the HostTopN data as follows:

10 * Value for the RMON Max Host parameter

Refer to the previous section for information on setting the RMON Max Host parameter.

Matrix Group

When you enable the DCM, the default setting (Enabled) for the RMON Default Matrix parameter causes the DCM to set up a Matrix configuration. To prevent creation of a Matrix configuration, set the RMON Default Matrix parameter to Disabled before you enable the DCM as described in the “[Activating DCM](#)” section.

Some RMON network management applications expect the DCM to set up a Matrix configuration, while others set up their own configurations.



NOTE: *The RMON agent allows you to create only one Matrix configuration. Be sure to set the RMON Default Matrix parameter according to the expectations of the RMON network management application.*

The Matrix configuration requires 212 bytes. The Matrix data requires approximately 178 bytes of memory per source/destination pair the DCM detects on a segment.

Filter and Capture Groups



Caution: *The memory you need for a Filter/Capture configuration and for storing captured packets can easily exhaust all the available memory on a DCM, particularly if the filters are not selective.*

You must create Filter and Capture configurations through your RMON network management application. You can create as many filters and capture buffers as memory permits, up to the RMON limit of 65,535 configurations.

Memory requirements vary greatly according to the size and number of the filters and the size of the capture buffer. In most cases, you need 3 to 5 KB of memory for the Filter and Packet Capture configuration.

The size of the capture buffer determines the amount of memory you need for the data. You can request the largest buffer size available by specifying a buffer size of -1 through your RMON network management application. When you specify -1 for the capture buffer size, the agent attempts to allocate a default buffer depending on the DRAM in the DCM ([Table 6-3](#)).

Table 6-3. Default Size for Capture Buffer

Installed DRAM (MB)	Default Buffer Size (KB)
2	32
4	64
8	256
16	512

You can also request a larger buffer size up to 15 MB. In any case, if there is not enough memory currently available to satisfy the request, the agent will provide a buffer that uses all available memory.

You can determine the maximum number of packets that an agent can capture in a buffer as follows:

buffer size/(packet slice size + 20 bytes)

Example

You specify a buffer size of 32 KB and a packet slice size of 1 KB. After checking the available memory, the RMON agent allocates the buffer size you requested. The buffer can hold a maximum of $32,768 / (1024 + 20)$ or 31 packets.



NOTE: *The RMON agent allocates the full amount of memory you specify for the packet slice size to each packet, even if the packet size is smaller than this amount. For this reason, Bay Networks recommends that you set the packet slice size to the smallest size possible. The maximum packet size is 2 KB.*

Appendix A

Troubleshooting Network Boot Problems

Use the information in the following sections of this appendix to resolve problems directly related to startup and connectivity with remote routers.

- Solving Startup Problems
- Identifying Remote Connectivity Problems
- Resolving Connectivity Problems
- Maintaining the Router Software



Note: *For most troubleshooting information, see Troubleshooting Routers.*

Solving Startup Problems

This section helps you isolate and solve the four most common router startup problems. Refer to the appropriate section:

- Router Fails to Get IP Address
- Router Fails to Netboot
- Router Fails to Perform Directed Netboot
- Router Netboots, but Fails to Load Applications

Router Fails to Get IP Address

If a message at the router console indicates that the router failed to get an IP address from the upstream router, or if the upstream router is failing to receive BOOTP requests or respond to them, make sure the network cable between the router's synchronous port and the upstream router is firmly connected. Then refer to the instructions in one of the following sections until you find and correct the problem:

- Upstream Router Not Receiving BOOTP Requests
- Upstream Router Not Sending BOOTP Responses

Contact the Bay Networks Technical Response Center if you follow the instructions in these sections and cannot find and correct the problem.

Upstream Router Not Receiving BOOTP Requests

If the upstream router is not receiving BOOTP request messages, use the **getcfg** command to display the router parameters and the **bconfig** and **ifconfig** commands to correct them if necessary. Refer to “[Displaying Parameter Settings](#)” and “[Debugging the BOOTP Server](#)” later in this appendix if you need instructions.

Upstream Router Not Sending BOOTP Responses

If the upstream router is receiving BOOTP request messages but failing to send BOOTP responses, use Site Manager to do the following:

1. **Make sure the upstream router's interface to the AN/ANH is enabled.**
2. **Make sure BOOTP is enabled on the circuit connecting the AN/ANH to the upstream router.**
3. **Make sure the upstream router's link modules and drivers are loaded.**
4. **Make sure the upstream router's IP protocol is enabled.**
5. **Make sure the upstream router's BOOTP protocol is enabled.**
6. **Make sure the BOOTP relay agent forwarding table associated with the upstream router shows a valid IP address that is configured on the IP router.**
7. **Make sure the input IP address is correct.**

8. **If you are using EZ-Install over a Frame Relay permanent virtual circuit (PVC) in group access mode, make sure the upstream router's BOOTP client interface table is configured properly.**

Router Fails to Netboot

If the router fails to receive the configuration file or image using a network boot option, first

- Make sure that all cables between the router and the BOOTP server are firmly connected.
- If using the **ifconfig** command, be sure to specify the boot image *krnl_an.exe* (not *an.exe*).

Then refer to the instructions in the following sections until you find and correct the problem:

- Upstream Router Not Receiving BOOTP Requests
- Router Not Sending BOOTP Responses
- BOOTP Server Not Sending BOOTP Responses

If you have not isolated the problem to a specific interface, retrieve the number of BOOTP packets forwarded and dropped from all routers between the router and the BOOTP server. Refer to “Displaying the Number of Packets Forwarded and Dropped” later in this appendix.

Contact your local Bay Networks Technical Response Center if you perform the instructions in these sections and cannot find and correct the problem.

Upstream Router Not Receiving BOOTP Requests

If the upstream router is not receiving BOOTP request messages, do the following:

1. **Execute the Technician Interface `getcfg` or `ifconfig` command to display the router parameters and the `bconfig` command to correct them if necessary.**

Refer to “Displaying Parameter Settings” and “Debugging the BOOTP Server” later in this appendix if you need instructions.

2. **Make sure that you enter the proper command at the router console to configure the AN/ANH's initial IP interface.**

Refer to “Configuring the Netboot Interface” in [Chapter 5](#) if you need instructions.

3. **Make sure that the AN/ANH's synchronous port configured for EZ-Install is cabled to the upstream router, or that the port configured for Netboot (synchronous or Ethernet) is cabled properly.**

Router Not Sending BOOTP Responses

If a router is receiving BOOTP request messages but failing to return BOOTP responses, do the following:

1. **Use Site Manager to make sure the BOOTP relay agent forwarding table associated with the router shows an IP address that is configured on the IP router.**
2. **Make sure that the input IP address is correct. If the Hops count is lower than the router's position in the path, increase it.**

Refer to “[Creating the BOOTP Client Interface Table](#)” in [Chapter 4](#) if you need instructions.

3. **Use the Configuration Manager to make sure that BOOTP and IP are enabled on the incoming and outgoing interfaces.**
4. **Make sure that the link modules and drivers are enabled. Refer to *Configuring Routers* if you need instructions.**

BOOTP Server Not Sending BOOTP Responses

If the BOOTP server is receiving BOOTP requests but failing to respond to them, do the following:

1. **Follow the instructions in the section “Displaying the BOOTP Server's IP Routes” later in this appendix.**
2. **Follow the instructions in the section “Debugging the BOOTP Server” later in this appendix.**
3. **Make sure that the `/etc/inetd.conf` file contains no more than one bootps entry.**

If there is more than one entry, comment out the invalid entry. The valid entry should be

```
bootps dgram udp wait root /etc/bootpd bootpd
```

4. **Make sure that the tftp dgram entry in the `/etc/inetd.conf` file is correct for your system.**

Refer to “Setting Up a TFTP Server” in [Chapter 3](#).

5. **Refer to “Verifying the BOOTP Server Setup” later in this appendix.**

Router Fails to Perform Directed Netboot

If the AN/ANH fails to perform Directed Netboot, do the following:

1. **Make sure that the interface that connects the AN/ANH to the TFTP file server is configured with an IP address.**
2. **Make sure that all necessary files are, in fact, residing on the TFTP file server.**
3. **Make sure the boot file is `krnl_an.exe` (not `an.exe`).**

Contact your local Bay Networks Technical Response Center if you perform the instructions in these sections but still cannot find and correct the problem.

Router Netboots, but Fails to Load Applications

If the AN/ANH Netboots a software image successfully, but displays an error message indicating that it cannot load specific applications, it is failing to retrieve files from the TFTP server that provided the software image. These files are necessary to perform functions such as running the protocols specified in the configuration file or displaying the log.

Do the following:

1. **Make sure that, after booting, you have at least one interface configured through which the file server that supplied the kernel image can be reached.**

This is necessary for a router that has obtained its image over the network to load application or string files.

2. **Make sure that all the application and string files (files with `.exe` and `.str` filename extensions) reside in the same directory as the kernel image.**

3. **Check that you have TFTP on the router. To determine this, display the router's loadmap screen message.**

If *tftp.exe* is missing, load it onto the router.

4. **Use Site Manager to make sure that IP is enabled and TFTP is created in the AN/ANH's configuration file.**

Refer to "Verifying the BOOTP Server Setup" later in this appendix.

5. **Use Technician Interface commands to verify or correct the status of the synchronous or Ethernet connectors used for network booting.**

Refer to *Using Technician Interface Software* for instructions. Following are some examples of AN/ANH commands and their responses, as well as some connector and interface settings you should consider:

- Enter the following command to display the router driver:

get wfLinkModules.15.0

The following response indicates that the AN/ANH driver is configured to run in Slot 1 (the only AN/ANH slot):

```
wfLinkModules.wfANLoad.0 = 2147483648
```

The decimal number 2147483648 represents Slot 1. If the setting is not 2147483648, enter the following command to correct it:

set wfLinkModules.15.0 2147483648;commit

- To display the drivers that are configured to run, enter the following command:

get wfDrivers.*.0

A combination of the following settings should appear within the list of drivers, according to your AN or ANH configuration:

```
wfDrivers.wfQsccSyncLoad.0 = 2147483648 COM ports
```

```
wfDrivers.wfQsccEnetLoad.0 = 2147483648 Ethernet ports  
                                         (nonrepeating)
```

```
wfDrivers.wfRptrLoad.0 = 2147483648 Ethernet repeater  
                                         ports (ANH only)
```

```
wfDrivers.wfTMS380Load.0 = 2147483648 Token Ring ports
```

Use the **set** command to correct any settings that are incorrect. For example, if the router has a Token Ring port and the `wfDrivers.wfTMS380Load.0` setting is not 2147483648, enter the following command to correct it:

set wfDrivers.wfTMS380Load.0 2147483648;commit

- If the router is Netbooting with a synchronous connector, enter the following command to display the information about the connector, where *<connector>* is the connector number:

get wfSyncEntry.*.1.<connector>

Make sure that external clocking is set.

- If the router is Netbooting with an Ethernet connector, enter the following command to display the information about the connector, where *<connector>* is the connector number:

get wfCSMACDEntry.*.1.<connector>

Identifying Remote Connectivity Problems

The sections that follow provide guidelines for isolating a router addressing problem or a Netboot problem. Refer to the appropriate section.

- Displaying Messages from the AN/ANH Console
- Displaying Statistics and Error Messages
- Guidelines for Using Packet Capture
- Guidelines for Using a LAN Protocol Analyzer

Displaying Messages from the AN/ANH Console

If you cannot connect to the AN/ANH using Site Manager, we recommend that you connect the AN/ANH to a modem or console.

If you cable the AN/ANH to a modem, you can dial in and connect to the AN/ANH remotely. This setup provides the same capabilities as an on-site console connection. Modem communications, however, are slower.

Viewing an AN/ANH error message and entering commands through a modem connection may simplify troubleshooting if you are not at the AN/ANH site. As an alternative, you can ask the person at the AN/ANH site to read the console messages to you and then you can enter the commands you want.

Displaying Statistics and Error Messages

Use the Statistics Manager Quick Get tool or the Technician Interface **get** command to display the number of BOOTP and TFTP packets forwarded and dropped for each interface in the path between the AN/ANH and the BOOTP server. Use the Events Manager tool or the Technician Interface **log** command to display the events associated with the interface and the BOOTP and TFTP protocols.

Refer to *Managing Routers* for instructions on using the Statistics Manager's Quick Get tool and the Events Manager. That guide also describes each event displayed in the log.

Refer to *Using Technician Interface Software* for instructions on using the **get** and **log** commands.

Guidelines for Using Packet Capture

Use the Packet Capture utility to view incoming or outgoing BOOTP or TFTP packets and isolate errors to a specific router interface. This utility is available through the Technician Interface on routers running Version 7.80 or higher.

Refer to *Using Technician Interface Software* for instructions on how to use Packet Capture. Refer to *Configuring SNMP, BOOTP, DHCP, and RARP Services* for a description of BOOTP packets.



Note: The instructions that follow assume that Version 7.80 or higher is running on all routers in the path between the AN/ANH and the BOOTP server.

Use Packet Capture as follows:

1. **Test the BOOTP server's next-hop router in the path to the AN/ANH.**
2. **Test the upstream router's interface to the AN/ANH.**
3. **Test the upstream router's interface to the next-hop router.**

4. **Test the interfaces that receive and forward the BOOTP and TFTP packets of the router in the middle of the path.**
5. **Continue testing each router in the path until you isolate the problem interface.**

Guidelines for Using a LAN Protocol Analyzer

Refer to the following guidelines when you use a LAN protocol analyzer:

- If Netboot is failing, connect the analyzer to the BOOTP server interface to determine whether it is receiving and responding to Netboot and TFTP requests.

To read the ASCII translation, view the BOOTP reply packets for the configuration file pathname in hexadecimal mode.



Note: *The LAN protocol analyzer does not decode all of the vendor tag fields.*

- If the BOOTP server is not receiving the requests, make sure the upstream router is receiving and forwarding them. If it is receiving, make sure each router interface between the upstream router and the BOOTP server is receiving and forwarding them.

If the BOOTP server is receiving requests, but failing to respond, refer to “Router Fails to Netboot” earlier in this appendix.

Resolving Connectivity Problems

This section describes how to

- Display the router’s Netboot parameter settings.
- Debug the BOOTP server.
- Verify the BOOTP server’s setup.
- Display the BOOTP server’s IP routes.
- Display the number of BOOTP packets forwarded and dropped.

Displaying Parameter Settings

Display the router parameter settings to determine

- Whether the AN/ANH is set to boot using a local boot image or a remote boot image
- Whether the AN/ANH is set to configure using a local configuration file or a remote configuration file
- The configuration of the synchronous and Ethernet connectors

Enter the following Technician Interface command to display the AN/ANH parameter settings:

getcfg

The following sample responses show the default settings for an AN or ANH with one Ethernet and two synchronous interfaces:

Boot Options

```
boot image=network
boot config=network
```

Netboot Parameters:

```
XCVR1..None
COM1...EZ-Install
COM2...EZ-Install
```

The possible `boot image` and `boot config` settings are `network` and `local`. If the setting is `network`, the AN/ANH requests the boot image or configuration file from a BOOTP server when booting. If the setting is `local`, the AN/ANH uses the boot image or configuration file stored in the Flash card file system.

The `XCVR` parameter shows the current setting of the AN/ANH Ethernet connectors. The `COM` parameters show the current settings of the AN/ANH synchronous connectors.

The possible settings for synchronous connectors are as follows:

- `EZ-Install` (the default setting)
- The IP address, next-hop IP address, subnet mask, and WAN protocol (Bay Networks HDLC or Frame Relay)

The possible settings for Ethernet connectors are as follows:

- None (the default setting)
- The IP address with subnet mask

See [Chapter 5](#) for instructions on using the **ifconfig** and **bconfig** commands to change the parameter settings.

Debugging the BOOTP Server

Debug the BOOTP server as follows:

1. **Enter the following command at the UNIX command line:**

bootpd -d -d&

The *bootpd* debugger tool reads the */etc/bootptab* file and generates the */etc/bootpd.dmp* file. The */etc/bootpd.dmp* file contains the portion of the */etc/bootptab* file that the *bootpd* debugger could read successfully. The debugger displays messages such as the following:

```
[1] 12914
```

```
hostname:/etc> reading "/etc/bootptab"
read 19 entries from "/etc/bootptab"
dumped 19 entries to "/etc/bootpd.dump".
```

2. **Compare the *bootptab* file to the *bootpd.dmp* file.**

If the *bootpd.dmp* file is truncated or is otherwise different from the *bootptab* file, BOOTPD may have encountered a syntax error. Find the inconsistency in the two files.

3. **Compare the inconsistency in the *bootptab* file to the sample *bootptab* file in [Chapter 3](#) (refer to [Figure 3-1](#)) and correct the error.**
4. **If you cannot find an inconsistency, boot the AN/ANH and view the *bootpd* debugger messages to determine the cause of the error.**

The sample messages in [Table A-1](#) show the sequence of messages when a BOOTP exchange is successful.

Table A-1. BOOTP Messages

Message	Explanation
hostname:/etc> request from IP addr 192.16.24.12	The UNIX hostname, the path (<i>/etc</i>) of the <i>bootptab</i> file, and the IP address of the AN/ANH.
found 192.16.24.12 AN.Boston	The IP address (192.16.24.12) mapped to the hostname, AN.Boston, in the <i>bootptab</i> file.
bootfile2 /\$HOME/.builder_dir/rel812/an krnl_an.exe	The pathname of the kernel file, as specified in the <i>bootptab</i> file.
Couldn't access /\$HOME/.builder_dir/rel812/an krnl_an.exe.AN.Boston	Disregard this message. The BOOTP server tries to access the host both by its name and by its IP address. The “couldn’t access” message means that the server tried to access a host named “AN.Boston” but failed because the AN is not named. The attempt to access the AN by its IP address succeeds, as you can infer from the last message.
vendor magic field is 99.130.83.99	Disregard this message.
sending RFC1048-style reply	The BOOTP server is sending a BOOTP response in compliance with RFC 1048.

Verifying the BOOTP Server Setup

Refer to these instructions if the BOOTP server is receiving BOOTP requests but failing to respond, or failing to forward the kernel, configuration, application, or string files.

Verify the BOOTP server setup as follows:

- 1. Make sure that the kernel image and all of the application (.exe) files are in the same directory.**

You can place these files in any directory you want. The Image Builder automatically generates the kernel image and application files when you open the software image file. By default, the Image Builder stores these files in the */\$HOME/.builder_dir/rel<rel>/an* directory, where *<rel>* is the current router software release for the AN/ANH.

For example, Version 2.12 of the Site Manager's Image Builder tool stores the Version 8.12 files in the `/$HOME/.builder_dir/rel812/an` directory.

2. **Make sure that the AN/ANH extracts the kernel image and all of the application and string files from the same software image.**

If these files are from different software versions, the AN/ANH may fail to boot or operate properly.

3. **Make sure that the *bootptab* file is in the `/etc` directory.**
4. **Make sure that the *bootptab* file contains the following entries:**

```
general:\
:hd=/$HOME/.builder_dir/rel812/an:\
:bf=krnl_an.exe:\
:bs=auto:\
:vm=rfc1048:
```

Note that `/$HOME/.builder_dir/rel812/an` is the default location of the kernel and all application and string files.

5. **Make sure that the *bootptab* file contains a definition for the particular AN/ANH that is failing to Netboot.**
6. **Make sure that the configuration filename and path are correct in the *bootptab* file.**

For example, the following *bootptab* line indicates that the configuration file named *AN_Bost.cfg* is in the `/rte3/cfg` directory path:

```
T129="/rte3/cfg/AN_Bost.cfg"
```

7. **Read the *bootptab* file carefully for misspellings or other errors.**

Compare it to the sample file shown in [Chapter 3](#) (refer to [Figure 3-1](#)).

Displaying the BOOTP Server's IP Routes

Enter the following command at the UNIX command line of the BOOTP server to display the IP address of the next hop to a netbooting router:

```
netstat -rn | grep -i -n <IP_address>
```

`<IP_address>` is the IP address of the netbooting router's network.
`|` is the vertical bar key (the UNIX pipe command).

For example, enter **netstat -rn | grep -i -n 192.32.155** to display the IP address of the next hop to the network address 192.32.155.

If the BOOTP server is receiving RIP advertisements of the netbooting router's network, a message such as the following appears:

```
121:192.32.155.0    192.32.13.53    UG    0    0    le0
```

The number 121 is the number of the entry in the workstation's static routing table. The number 192.32.155.0 is the IP address of the destination network. The number 192.32.13.53 is the address of the next-hop router. If the next-hop router is unavailable or wrong, refer to "Setting Up Static Routes to Next-Hop Routers" in [Chapter 3](#).

Displaying the Number of Packets Forwarded and Dropped

This section describes how to display the number of BOOTP packets forwarded and dropped by a router. Perform this procedure for each router between the router and the BOOTP server.

You can use either the Quick Get function of the Statistics Manager tool or the Technician Interface **get** command to retrieve this information. Refer to *Managing Routers* for additional information about Quick Get.

Quick Get Instructions

1. Select the following path:

```
wfApplication/wfInternet/wfBootpGroup/wfBootpRelayAgentGroup/  
wfBootpRelayIntfTable
```

2. To display the number of packets forwarded, select

```
wfBootpRelayIntfRequests
```

3. To display the number of packets dropped, select

```
wfBootpRelayIntfHopsDrops
```

Technician Interface Instructions

Enter the following command to display information that may help you determine if and why a device is dropping packets, where *<IP_address>* is the address of the interface receiving the packets:

```
get wfBootpRelayIntfEntry.*.<IP_address>
```

Maintaining the Router Software

The AN/ANH file system resides on the Flash memory card. This part of the router is *not* user-serviceable.

You use Technician Interface commands to maintain the local file system on the AN/ANH Flash card. See *Using Technician Interface Software* and *Using Technician Interface Scripts* for information.



Caution: *Be very careful when you use the **format** command with the router. This command erases all files on the local Flash card, and the router will not be able to local-boot an image or configuration file until you replace the files. You can avoid this situation by partitioning the Flash card media. See *Using Technician Interface Software and Managing Routers*.*

When Technician Interface commands require you to specify a volume, always specify Volume 1 for an AN/ANH.

Upgrading the Software Image

You can upgrade an AN/ANH's software image (*krnl_an.exe*) using one or both of the following options:

- Use Netboot to start the AN/ANH.

This option upgrades the image only in the AN/ANH's RAM.

- Use TFTP to transfer the image to the AN/ANH's local file system, then use Local Boot to start the AN/ANH.

This option upgrades the image in both the AN/ANH's local file system and in memory.



Caution: *If you use TFTP to transfer an upgraded image to an AN/ANH Flash card, and an interruption in the file transfer occurs (for example, if the AN/ANH resets, reboots, or loses power), the AN/ANH's local file system becomes corrupted and it cannot boot locally until the file system is restored.*

Restoring a Local File System

If the local file system becomes corrupted, you must restore it by upgrading the software image.

If for any reason the AN/ANH resets, reboots, or loses power while restoring or compacting its Flash card file system, it automatically Netboots the configuration file and software image. (Note that you must already have the network set up for Netboot to succeed.)

After the AN/ANH successfully Netboots, you can use TFTP to restore the software image and configuration file on the local file system.



Caution: *Compacting the file system on a Flash card can take up to 15 minutes. When you compact a router's file system, always let compaction complete before you reset the router.*

Appendix B

Local Boot: The Quick-Start Procedure

If you have read [Chapter 2](#) and want to use the Local Boot process to start an AN or ANH for the first time, use the information and worksheets in this appendix to gather the network information required to complete the Quick-Start procedure.



Note: *The worksheets in this appendix apply only to AN and ANH models. See Quick-Starting Routers for all other Bay Networks routers.*

The last section in this appendix, “[Running the Quick-Start Script](#),” provides information about the Quick-Start procedure.

What Is Quick-Start?

The Quick-Start procedure is the initial configuration that starts a locally booted router running on the network. The procedure enables Internet Protocol (IP) so that the router can connect to Site Manager.

Quick-Starting the router consists of running the *install.bat* script and entering information at the Quick-Start prompts. The router automatically selects options for some prompts, and you can accept default values for many of the other prompts.



Note: *The install.bat script allows for many possible configurations. Since typical remote access uses a synchronous interface over a wide-area connection, the following Quick-Start worksheets provide only the options involved with a synchronous configuration. When you configure a LAN interface, base your decisions on the information provided with each install.bat prompt.*

Using the Quick-Start Worksheets

This appendix includes a series of worksheets to help you organize the network information you need for your specific configuration and answer Quick-Start prompts. The worksheets contain the options for each prompt and provide space for you to record the options you select.

If you are not configuring the AN/ANH yourself, fill out the worksheets for a person at the AN/ANH site and relay the worksheet information. Written for a person at the router site, the manuals *Installing and Starting AN Routers* and *Installing and Starting 8-Port ANH Systems* include identical Quick-Start worksheets and include instructions for completing the Quick-Start procedure.

Prepare for Quick-Start as follows:

1. **Fill out the Global Information Worksheet completely.**

This worksheet lists options common to all synchronous interface configurations.

2. **After you record your protocol selections on the Global Information Worksheet, fill out *one* Router Protocol worksheet.**

This worksheet lists specific options for RIP, OSPF, or Static Route configurations. For example, if you select RIP as your routing protocol, you need only fill out the worksheet pertaining to RIP.

3. **Fill out *one* Wide-Area Protocol worksheet.**

This worksheet lists specific options for Bay Networks (proprietary) Point-to-Point Protocol (PPP), Frame Relay, Standard PPP, and Switched Multimegabit Data Service (SMDS) configurations. For example, if you select Frame Relay as your wide area protocol, you need only fill out the Frame Relay worksheet.

4. **Run *install.bat* as described “[Running the Quick-Start Script](#)” later in this chapter.**

Or, a remote-site operator runs the *install.bat* script as described in the hardware *Installing and Starting* guide.

5. **Once the ANH has an initial connection to the network, use the guide *Configuring Routers* to configure the AN/ANH using Site Manager.**

Global Information Worksheet

This section contains the prompts and possible options relating to all AN synchronous configurations. Write your selection in the “Your Response” column.

Global Information Worksheet

Step	Requested Information	Options	Your Response
1	Specify the slot number where the Link Module resides.	Because the AN is not a Link Module, the router bypasses this step and automatically accepts a default slot of “1.”	None.
2	Specify the Link Module and network interface information for the initial IP connection to Site Manager.	The AN automatically provides a representative letter code depending on the type of AN you have. The network interface options are — Ethernet — Token Ring — Synchronous Select the number associated with the synchronous interface.	
	Enter connector number [1]:	1. COM1 2. COM2 3. COM3	
	Enter clock source number [2]:	1. Internal 2. External	
	Enter circuit name [S#]:	The AN recommends a circuit name for the COM interface you select (for example, S11 for COM1 and S12 for COM2).	Press the Return key.

(continued)

Global Information Worksheet *(continued)*

Step	Requested Information	Options	Your Response
3	Enter IP address in dotted decimal notation:	Enter the IP address for the COM interface.	
	Enter the subnetwork mask in dotted decimal notation:	Enter the subnetwork mask for the COM interface IP address.	
	Is the router connected to the same local area network as the Site Manager workstation? (y/n) [n]:	y(es) n(o)	Press the Return key.
	Enter routing protocol number [1]:	1. RIP 2. OSPF 3. Static Route to Site Manager	(Complete the worksheet for the protocol you select.)
	Enter wide area protocol number [1]:	1. Bay Networks Point-to-Point Protocol (Proprietary) 2. Frame Relay 3. Point-to-Point Protocol (PPP) Standard 4. Switched Multimegabit Data Service (SMDS)	(Complete the worksheet for the protocol you select.)
	Do you wish to set SNMP community management? (y/n) [n]:	y(es) n(o) Setting up SNMP community management is optional.	
4	TFTP default volume [1]:	The AN automatically assigns the TFTP default volume to "1."	None
5	Do you want to enable TELNET? (y/n) [n]:	y(es) n(o) Enabling TELNET is optional.	
6	FTP default volume [1]:	The AN automatically assigns the FTP default volume to "1."	
7	Do you wish to save this configuration to a file? (y/n) [y]	y(es) n(o)	Press the Return key.
	Enter filename [<i>startup.cfg</i>]:	We recommend using the default filename.	Press the Return key.

Router Protocol Worksheets

This section contains requested information and possible options relating to the routing protocol choices on the Global Worksheet.

RIP Worksheet

Requested Information	Options	Your Response
Should RIP listen to the default route? (y/n) [n]:	y(es) n(o) Note: RIP listens to a specific network or subnet route where Site Manager is located. Answering y(es) to this request forces RIP to also listen to the default route (0.0.0.0). This is useful when no specific route is available in the RIP updates that the router receives.	

OSPF Worksheet

Requested Information	Options	Your Response
Enter the OSPF router ID in dotted decimal notation [the router provides the IP address of the COM port]:	Enter an IP address to uniquely identify the router in the OSPF domain. We suggest using the default IP address provided.	
Enter the OSPF area ID in dotted decimal notation [0.0.0.0]:	Enter the area ID. This ID must match the area ID of the router's neighbor. Note: The backbone area ID is always 0.0.0.0.	

(continued)

OSPF Worksheet *(continued)*

Requested Information	Options	Your Response
Enable Simple Password authentication? (y/n) [n]:	y(es) n(o) Note: If you answer y(es), the router requests a password.	Password: _____
Enter OSPF MTU size selection [1]:	1. Default 2. Ethernet size (Bay Networks Series 5 compatible) 3. User defined MTU	
Enter OSPF interface type selection [1]:	1. Broadcast 2. NBMA 3. Point-to-Point 4. Point-to-Multipoint 5. Point-to-Multipoint (STD) Note: When using a wide-area protocol other than Bay Networks Proprietary PPP, we suggest selecting NBMA.	
Enter decimal value in seconds for Hello Interval [10]: Note: This value must match all other interfaces in the OSPF area for connection to take place.	The AN suggests the following intervals: Broadcast — 10 seconds Point-to-Point — 15 seconds NBMA — 20 seconds Point-to-MultiPoint —10 seconds	
Enter decimal value in seconds for Router Dead Interval [40]: Note: This value must match all other interfaces in the OSPF area for connection to take place.	The AN suggests the following intervals: Broadcast — 40 seconds Point-to-Point — 60 seconds NBMA — 80 seconds Point-to-MultiPoint (STD) — 40 seconds	

(continued)

OSPF Worksheet *(continued)*

Requested Information	Options	Your Response
Enter decimal value for Router Priority [1]: (For Broadcast, NBMA or Point-to-MultiPoint)	Enter a router priority value. The lower the value (above zero), the higher the priority. Note: If you set the router priority to zero (0), the router is not eligible to become the designated router on this particular network.	
Enter decimal value in seconds for Poll Interval [20]: (For NBMA only)	Enter the largest number of seconds allowed between Hello packets the router sends to an inactive NBMA neighbor. The router suggests a 20-second interval.	
Enter IP address of neighbor in dotted decimal notation or enter q to quit: (For NBMA only)	Enter addresses for all NBMA neighbors you want the router to communicate with. Enter q and press the Return key when you finish entering addresses.	
Enter IP address of neighbor in dotted decimal notation: (For PPP only)	Enter addresses for the PPP neighbor you want the router to communicate with.	

Static Route to Site Manager Worksheet

Requested Information	Options	Your Information
Destination Network [0.0.0.0]:	Enter the gateway address of the destination network. An address of 0.0.0.0 specifies the default route.	

(continued)

Static Route to Site Manager Worksheet *(continued)*

Requested Information	Options	Your Information
Destination Network Mask [0.0.0.0]:	Enter the subnetwork mask of the destination network. A mask of 0.0.0.0 specifies the default route.	
Next-Hop Address:	Enter a next-hop address. All static routes require a next-hop address in the same subnet as the initial IP interface.	

Wide-Area Protocol Worksheets

This section contains requested information and possible options relating to wide-area protocol choices on the Global Worksheet.

Bay Networks Proprietary PPP Worksheet

Requested Information	Options	Your Information
Enter BOFL (Breath of Life) timer value (1-60) [5]:	Enter the maximum amount of time that can elapse between the successful transmission of BOFL messages.	
Enter Local Address Selection [3]:	1. DCE 2. DTE 3. EXPLICIT Note: Reverse local and remote address values when configuring the device at the other end of the circuit. (Exception: When connecting to a Series 5 router that uses DCE/DTE addressing, use the SAME local address value.)	

(continued)

Bay Networks Proprietary PPP Worksheet *(continued)*

Requested Information	Options	Your Information
Enter Remote Address Selection [3]:	1. DCE 2. DTE 3. EXPLICIT Note: Reverse local and remote address values when configuring the device at the other end of the circuit. (Exception: When connecting to a Series 5 router that uses DCE/DTE addressing, use the SAME local address value.)	

Frame Relay Worksheet

Requested Information	Options	Your Information
Enter Management type [3]:	1. DLCMI None 2. Rev 1 LMI 3. ANSI T1 617D 4. CCITT Annex A 5. LMI Switch 6. Annex D Switch 7. Annex A Switch	
Enter addressing type [4]:	1. ADDR Q.921 2. ADDR Q.922 (MARCH '90) 3. ADDR Q.922 (NOVEMBER '90) 4. ADDR Q.922	
Enter address field length:	2. Two Bytes 3. Three Bytes 4. Four Bytes	
Enter DLCI number [30]: (For DLCMI None, LMI Switch, Annex D Switch, and Annex A Switch only)	Enter the Permanent Virtual Channel (PVC) number. Note: The valid range for the DLCI number is between 16 and 1007.	

PPP Standard Worksheet

Requested Information	Options	Your Information
Enter Remote IP address in dotted decimal notation:	Enter the IP address of the peer connection.	
Do you wish to turn on the PPP echo function? (y/n) [n]:	y(es) n(o)	
Enable PAP (Password Authentication Protocol)? (y/n) [n]:	y(es) n(o) Note: If you answer y(es), the router requests a PAP ID and password for this interface. If you answer n(o), the router asks whether you want to enable CHAP.	
Enable CHAP (Challenge Handshake Authentication Protocol)? (y/n) [n]:	y(es) n(o) Note: If you answer y(es), the router requests a CHAP secret for this interface.	
Does the Remote Peer have PAP authentication enabled? (y/n) [n]:	y(es) n(o) Note: If you answer y(es), the router requests the PAP ID and password for the remote interface.	
Enable the LQR (Link Quality Reporting) Protocol? (y/n) [n]:	y(es) n(o) Note: Link Quality Monitoring on a Bay Networks Series 5 router is not compatible with this feature.	

(continued)

PPP Standard Worksheet *(continued)*

Requested Information	Options	Your Information
Enable use of the Remote Peer router's LQR Timer? (y/n) [y]: (For LQR Protocol only)	y(es) n(o) Note: If the LQR timer is enabled, the remote peer router maintains its own LQR timer for this interface. When the LQR timer is disabled, the AN is responsible for maintaining the timer for this interface.	
Number of seconds (1-120) [3]: (For LQR Protocol only)	Enter the maximum number of seconds between the transmission of LQR packets.	
Enter [inbound] success rate percentage (1-100) [90]:	Enter the minimal acceptable success rate (percentage) of packets transmitted by the peer router and received on this interface over the last 5 LQR reporting periods.	
Enter [outbound] success rate percentage (1-100) [90]:	Enter the minimal acceptable success rate (percentage) of packets transmitted by this interface and received by the peer router over the last 5 LQR reporting periods.	

SMDS Worksheet

Requested Information	Options	Your Information
Enter 10-digit individual address:	Enter the individual address assigned to you by your SMDS service provider.	
Enter 10-digit group address:	Enter the group address assigned to you by your SMDS service provider.	
Enter 10-digit arp address:	Enter the Address Resolution Protocol (ARP) address assigned to you by your SMDS service provider.	

Running the Quick-Start Script

You run the Quick-Start script as part of the Local Boot process. Begin Local Boot as follows:

1. **At the Technician Interface login: prompt, type Manager and press the Return key to log in.**

Be sure to have the completed worksheets with you.

2. **Type `bconfig config local` and press the Return key to configure the router to use the local *config* file when booting.**

For information about the **bconfig** command, see “[Configuring the Router Boot Source](#)” in [Chapter 5](#).

3. **Reboot the AN/ANH (type `boot` and press the Return key).**

The Technician Interface login prompt appears.

4. **Log in to the AN/ANH Technician Interface.**

The Technician Interface mounts the local file system and displays a prompt indicating the present working directory.

5. **Type `run install.bat` and press the return key to begin the Quick-Start procedure.**

6. Follow the script online, using your worksheets for responses to its prompts.

Refer to the list of Quick-Start commands in [Table B-1](#).

Table B-1. Quick-Start Commands

To Do the Following	Action	Details
Accept a default value	Press Return	Your console displays default values in brackets; for example, [E11].
Repeat a step (for example, if you make a mistake)	Press Control-c Press n	When prompted, "Terminate script y/n?" press the n key. You return to the beginning of the step so you can re-enter the information.
Stop the Quick-Start installation procedure	Press Control-c Press y	When prompted, "Terminate script y/n?" press the y key. The Quick-Start procedure is terminated and you return to the Technician Interface prompt. To restart the Quick-Start procedure, you must reboot the router by entering boot and pressing the Return key.

The ANH progresses through the Quick-Start script as follows:

- The Quick-Start script begins prompting for the initial Global Worksheet information.
 - The script prompts for specific protocol information.
 - The script requests a wide-area protocol selection.
 - The script prompts for specific protocol information.
 - The script prompts for the rest of the Global Worksheet information.
 - After you enter all of the Global Worksheet protocol information, the Quick-Start script displays a Configuration Summary and prompts you to save the configuration to a file.
- 7. Name and save the configuration file.**

The script begins to test the configuration on the new IP interface ([Figure B-1](#)).

```
Testing local IP interface

ping -IP 192.32.00.000 -r5
IP ping: 192.32.00.000 is alive (size - 16 bytes)
IP ping: 192.32.00.000 is alive (size - 16 bytes)
IP ping: 192.32.00.000 is alive (size - 16 bytes)
IP ping: 192.32.00.000 is alive (size - 16 bytes)
IP ping: 192.32.00.000 is alive (size - 16 bytes)

This test attempts to ping the Site Manager workstation.

NOTE: If routing has not yet converged, an attempt
      to ping the Site Manager workstation may fail. If
      this happens, you may either enter a new IP address or
      quit and wait a short period of time and try again from
      the TI command line.

Type q<return> to cancel this test.

Enter IP address of Site Manager workstation:
```

Figure B-1. Starting the IP Interface Test

- 8. To continue the IP configuration test, enter the IP address for the Site Manager workstation.**

To cancel the test, enter **q**.

- 9. When the ANH Technician Interface prompt reappears, type logout and press the Return key to exit the Technician Interface.**

Once the AN/ANH creates and tests the configuration, it starts using the configuration information you entered. Refer to *Configuring Routers* to configure the router using Site Manager.

Appendix C

Implementation Notes

This appendix contains implementation hints, a few important notes you could have missed earlier in this guide, and guidelines for planning ANH network configurations.

Hints

This section contains a few hints for setting up an AN or ANH.

- We recommend that you first install an AN/ANH in the same site as your BOOTP server, Site Manager workstation, and intermediate Bay Networks routers to test the software image, configuration file, and routing path. This test provides you with the startup and troubleshooting experience you need to perform these tasks on routers at remote sites. After you perform the test, move the test router to the remote location you want, modify the configuration file for that router, and set up the new paths.
- After you build and test the remote router configuration file, make copies of it on the Site Manager workstation. Then modify the copies for each AN/ANH in your network, rather than starting over. To avoid mix-ups, make sure the filename you assign to each configuration file is unique and meaningful for each router.
- It may be easier to isolate BOOTP and TFTP configuration errors on the network if you upgrade all Bay Networks routers in the paths between the routers and the BOOTP server to Version 7.80 or higher before you set up the paths.

- If you are using EZ-Install over Frame Relay to boot an AN/ANH, you can have up to 20 PVCs for a single Frame Relay interface on the upstream router. If you have more than 20 PVCs on the interface where EZ-Install is occurring, the EZ-Install process may fail. To ensure that the process does not fail, configure no more than 20 PVCs for a Frame Relay interface.
- If the AN/ANH will have small routing or forwarding tables, you can increase performance by reducing local memory and allocating more global memory for buffers. If the AN/ANH will have large tables (for example, more than 500 servers), you might want to increase the local memory allocation.

Notes

- If you use TFTP to transfer the software image file to upgrade or restore the router's file system, be sure to specify the AN/ANH image (*an.exe*).
- Bay Networks supports BOOTP service on UNIX workstations, but not PCs. If you want to use Netboot and you are using a PC as your Site Manager workstation, transfer the files you want to Netboot from the PC to a UNIX workstation and configure the workstation as a BOOTP server.
- You cannot use EZ-Install or Netboot directly from a Token Ring or FDDI interface.
- You need Version 8.10 or higher to perform Directed Netboot.
- If you have a LAN protocol analyzer available, you may want to use it to troubleshoot BOOTP server communication errors. (Appendix A provides guidelines for using Packet Capture and an analyzer to isolate these errors.)
- Versions prior to 7.80 do not include the Technician Interface Packet Capture utility.
- The 12-port ANH polls the internal repeater module for operation status; it does not poll individual Ethernet repeater ports for connection (link) status. Therefore, the 12-port ANH is aware of the connection between the base board and repeater module, but is not aware of any connection between the repeater module and the Ethernet network. If the repeater module interface state reports an operational status, the 12-port ANH may continue to transmit information through the repeater module even though a physical Ethernet connection does not exist.
- You can issue a **boot** command from the Diagnostic Monitor prompt and specify a local boot by using 1: as the volume name.

- When at the diagnostic prompt, you cannot view the contents of Flash memory. Be extremely careful to remember the name of the configuration file when doing a named boot from the Diagnostic Monitor prompt.

Network Configuration Options

This section describes several options for configuring an ANH in a network. It provides general requirements and recommendations for network configurations using the ANH, as well as examples of valid configurations.

The basic configuration uses a standalone ANH in a departmental network (see the section “Configuring a Single ANH”). To accommodate more stations, you can connect (*daisy-chain*) multiple ANH systems (see the section “Configuring Multiple Hubs”).



Note: *The examples and illustrations in this section show the 8-port ANH, but they apply to any Bay Networks ANH system.*

Ensuring Ethernet Network Compliance

Before configuring any network hardware, use the following rules to assess your network for compliance with Ethernet operating standards. (Using these rules allows you to avoid performing the detailed calculations specified in the IEEE 802.3 specifications.)

The network is compliant when it meets all of the following requirements:

- No path through the network contains more than five repeaters.
- No more than 1024 stations are connected (not counting repeaters).
- The entire Ethernet network consists of only IEEE 802.3 components, using only AUI, 10Base-T, FOIRL, 10Base-F, 10Base-5, or 10Base-2 cables.
- Fiber-optic link attenuation limits are met. (Refer to the attenuation specifications for the fiber-optic cable, connectors, and transceiver or device transmitter/receiver ports that you are using.)
- No link is longer than the IEEE 802.3 maximums, given in Table [C-1](#).

Table C-1. IEEE 802.3 Maximum Segment Links

Segment Type	Maximum Segment Length (m)
10Base-5 (coaxial)	500
10Base-2 (coaxial)	185
10Base-T	100
10Base-FB	2000
10Base-FL	2000
FOIRL	1000
AUI drop	50 (2-m allowance + 48-m excess)

Network paths composed of three or four repeaters must also comply with the following additional restrictions.

Network Path Containing Three Repeater

In the longest path containing three repeaters, no transmit-end or receive-end fiber link can be longer than 400 meters (m).

Network Path Containing Four Repeater

In the longest path containing four repeaters:

- No more than three links are maximum-length coaxial segments.
- No fiber link is longer than 500 m; or, if one or more is longer, the total of all fiber links does not exceed 2500 m (2740 m if all are 10Base-FB).

Configuring a Single ANH

The basic ANH configuration consists of one ANH, one local management console, and as many as nine 10Base-T devices in a standalone local area network configuration.

You can directly connect as many as eight 10Base-T Ethernet stations into a local Ethernet segment using a single 8-port ANH.



Note: You can add a ninth Ethernet station to the AUI port using a 10Base-T transceiver. The section “Configuring an AUI Port” describes other options for using the AUI port.

Figure C-1 shows an example of a single ANH network configuration. UTP distribution cables connect Ethernet stations that have either an installed 10Base-T network interface card (NIC) or an AUI NIC plus an external 10Base-T transceiver.




Figure C-1. Typical Single-ANH Configuration



Note: In [Figure C-1](#), the local management station (directly connected through the console port) can be either an ASCII- or PC-based terminal. In larger network configurations, you can also connect the ANH to an SNMP management station through a 10Base-T repeater port (see [Figure C-4](#)).

Configuring Multiple Hubs

You can interconnect as many as four ANH units using the UTP repeater ports.



Note: *Backbone connections are usually made through the AUI port (see the section “Configuring an AUI Port”).*

When you configure a network with multiple ANH (or other repeater/hub) systems, you must comply with the following rules:

- Connect no more than four hubs.
- Make sure each UTP connection is no longer than 100 m.
- If a transceiver is connected to the AUI port, disable the SQE (signal quality error) test function of the transceiver.



Note: *Minimize the number of repeaters between stations in the network by connecting hubs in a star configuration. Avoid chaining hubs in a single line.*

When connecting three or four hubs, make sure the installation complies with the specifications in “Ensuring Ethernet Network Compliance” earlier in this chapter.

[Figure C-2](#) shows an ANH linked with two Model 810M hubs. UTP patch cables connect each MDI port to an MDI-X port. For information about activating the MDI-X/MDI switch, see *Installing and Starting BayStack ANH Systems*.




Figure C-2. Connecting the ANH with Other Hubs

Configuring an AUI Port

You can connect any IEEE 802.3 media attachment unit (MAU) to the AUI port on an AN or ANH. For example, you can use an IEEE 802.3 10Base-FL fiber-optic MAU (FOMAU) to connect to a fiber-optic port on a router or hub. Or, you can connect the AUI port to a coaxial backbone through an IEEE 802.3 10Base-5 or 10Base-2 MAU.



Caution: *IEEE 802.3 rules require that the SQE test function be disabled on an IEEE 802.3 MAU connected to an AUI port. If it is not disabled, the AUI port could interrupt network transmissions until it autopartitions (automatically goes off-line after 32 consecutive collisions).*

Connecting the AUI Port to a Fiber-Optic Backbone

To connect an AN or ANH to a fiber-optic backbone, you must first connect an IEEE 802.3 10Base-FL (or 10Base-FB) transceiver to the AUI port.

Figure C-3 shows an example network with two 8-port ANH systems connected via a fiber-optic backbone. An AUI cable connects each ANH to a transceiver that has the SQE test function disabled. A fiber-optic cable connects the two transceivers.




Figure C-3. Connecting Two ANH Systems Using 10Base-FL Transceivers

Connecting the AUI Port to a Coaxial Backbone

You can use the AUI port to connect an AN or ANH to a coaxial backbone through an IEEE 802.3 10Base-5 or 10Base-2 coaxial MAU.

Figure C-4 shows two ANH systems connected to a coaxial backbone through IEEE 802.3 MAUs. An AUI cable connects the AUI port on each ANH to each MAU. The SQE test is disabled on each MAU connected to the AUI port on an ANH.




Figure C-4. Connecting ANH Systems through a Coaxial Backbone

Symbols

[/etc/inetd.conf file, 3-8, 3-9](#)
[/etc/services file, 3-2](#)
[/tftpboot directory, 3-9](#)
[/usr/wf/config directory, 3-3](#)
[12-repeater port AN. *See* ANH](#)
[8-repeater port AN. *See* ANH](#)

A

[address. *See* IP address](#)
[addresses window](#)
 [BOOTP, 4-17](#)
[AIX](#)
 [BOOTPD, 3-2](#)
 [TFTPD access, 3-9](#)
[an.exe, 1-6, A-3, C-2](#)
[analyzing packets](#)
 [on a router, A-8](#)
 [on the BOOTP server, A-9](#)
[ANH](#)
 12-port
 [disabling, 6-6](#)
 [port status, 6-6](#)
 [status, C-2](#)
 [thirteenth port, 6-6](#)
 8-port
 [AUI interface, 6-5](#)
 [DCM option, 6-7](#)
 [ninth port, 6-5](#)
 [port status, 6-5](#)
 [AUI connections, C-5](#)
 [compliance rules, C-4](#)

[configuring](#)
 [in a network, C-3 to C-9](#)
 [multiple, C-6](#)
 [single, C-4](#)
 [enabling ports on, 6-4](#)
 [repeater ports](#)
 [autopartitioning, C-7](#)
 [enabling, 6-4](#)
 [managing, 6-1](#)
 [resetting and testing, 6-1 to 6-3](#)
[application files, 1-6](#)
 [generating, 4-3](#)
[applications, troubleshooting, A-5](#)
[AUI connections, 1-3](#)
 [ANH, C-5](#)
 [coaxial backbone, C-9](#)
 [disabling SQE test function, C-6](#)
 [examples, C-7 to C-9](#)
[automated addressing. *See* IP address](#)

B

[backbone](#)
 [coaxial, C-9](#)
 [fiber-optic, C-8](#)
[base record, DCM, 6-22](#)
[basic rate interface \(BRI\), 1-4](#)
[Bay Networks](#)
 [CompuServe forum, xvii](#)
 [customer support, xvii](#)
 [Home Page on World Wide Web, xviii](#)
 [InfoFACTS service, xviii](#)
 [publications, ordering, xxi](#)

-
- Technical Response Center, xix
 - Bay Networks Proprietary PPP protocol
 - worksheet for, B-8
 - Bay Networks Standard protocol, 4-19, 5-4
 - bconfig command
 - examples, 5-3
 - format, 5-2
 - bf (boot file) tag, in bootptab file, 3-6
 - boot
 - DCM board, 6-18
 - failure, 1-6
 - file tag, 3-6
 - getcfg command display, A-10
 - process, 1-9
 - size tag, 3-6
 - while writing to a file, A-16
 - Boot Config From Network parameter, 4-6
 - Boot Config Pathname parameter, 4-7
 - Boot Image From Network parameter, 4-5
 - Boot Image Pathname parameter, 4-7
 - Boot Server Address parameter, 4-6
 - BOOTP, 3-1 to 3-12
 - analyzing packets on a router, A-8
 - client interface table, 1-12, 4-19 to 4-21
 - example, 1-9 to 1-14
 - failure of, A-2
 - pass-through, enabling, 4-14
 - relay agent forwarding table, 4-15 to 4-18
 - relay, enabling, 4-14
 - Site Manager support, C-2
 - socket, 3-2
 - testing, C-1
 - BOOTP server
 - analyzing packets, A-9
 - debugging, A-11
 - displaying IP routes, A-13
 - location of files, 4-2
 - not receiving BOOTP requests, A-4
 - responses, failure of, A-2
 - router software version, C-1
 - troubleshooting, A-4, A-12
 - BOOTP, addresses window, 4-17
 - BOOTPD
 - copying, 3-2
 - debugger tool, A-11
 - linking to TFTP, 3-9
 - send and receive sockets, 3-2
 - bootpd.dmp file, A-11
 - bootptab file, 3-3 to 3-7
 - debugging, A-11
 - symbols in, 3-5
 - syntax, 3-4
 - troubleshooting, A-12
 - broadcast address, 1-11
 - bs (boot size) tag, in bootptab, 3-6
- ## C
- clocking, synchronous interface, 5-4
 - COM ports. *See* synchronous interfaces
 - commands
 - bconfig, 5-2 to 5-3, A-2
 - for Local Boot, B-12
 - boot
 - Local Boot, B-12
 - getcfg, A-2, A-10
 - ifconfig, 5-4 to 5-7
 - run install.bat, B-12
 - compacting files, A-16
 - comparing startup options
 - initial boot, 2-1
 - routine boot, 2-3
 - compliance, Ethernet, C-3
 - CompuServe, Bay Networks forum on, xvii
 - config file
 - using local, B-12
 - configuration file, 4-2
 - corrupted, A-15
 - creating, 4-2
 - customized, 1-8, 1-15, 2-3
 - getting from a BOOTP server, 1-13 to 1-15
 - hint for creating, C-1
-

configuration file (cont.)

- preparing, 4-2
- restrictions, 4-2
- T130 size tag, 3-5

configuring

- Directed Netboot, 3-1, 5-1
- EZ-Install, 3-1, 4-1
- interface, 5-2
- Local Boot, B-1
- Netboot, 3-1, 5-1
- network, C-3 to C-9

connecting multiple ANHs, C-6 to C-9

Connector IP Address parameter, 4-11

Connector Next Hop parameter, 4-12

Connector parameter, 4-11

Connector Protocol Mask parameter, 4-12

Connector State parameter, 4-13

Connector Subnet Mask parameter, 4-12

console port, 1-1

cost of line usage, 1-8, 2-4

customer support. *See* getting help

D

daemon

- BOOTP, 3-2
- TFTP, 3-8

DCM

- about, 6-7
- configuring, 6-19, 6-22
- disabling, 6-18
- installing, 6-11
- parameters, 6-13
- reboot, 6-12, 6-18

DCMMW (DCM middleware), 6-7

debugging the BOOTP server, A-11

default IP interface settings

- Ethernet, 5-6
- synchronous, 5-4

deleting files, A-15

dialup access, A-7

direct access. *See* Frame Relay

Directed Netboot

- bconfig command, 5-3
- configuring
 - boot client, 5-1
 - interfaces for, 4-1
 - server location, 5-2
 - UNIX server, 3-1
- ifconfig command, 5-7
- requirements for, 1-8

DLCI and IP address pair, 4-19 to 4-21

- example, 1-12

DLCI Number parameter, 4-21

DLCMI settings, 5-5

driver, displaying MIB entry for, A-6

drivers, B-3

E

erasing files, A-15

error messages, displaying, A-7

Ethernet

- compliance, C-3
- displaying MIB entry, A-7
- interface connections, 1-1
- repeater ports, 1-3, 6-1
- segment lengths, C-4

Ethernet History group, 6-9, 6-25

Ethernet Statistics group, 6-9, 6-25

Events Manager tool, A-8

executable (.exe) files. *See* application files

EZ-Install, 1-10 to 1-15

- configuring, 3-1, 4-1
- initial startup option, 2-6
- maximum PVCs, C-2
- requirements, 1-7
- summary, 1-7
- troubleshooting, A-2 to A-5

F

- failure, BOOTP, A-2, A-3
- FDDI interface limitation, C-2
- fiber-optic backbone, C-8
- files
 - corrupted, A-15
 - naming restrictions, 4-2
 - transferring. *See* TFTP
- Filter group, 6-10, 6-28
- Flash memory
 - EZ-Install boot image source, 1-7
 - Local Boot image source, 1-8
- format command, A-15
- forwarding table. *See* BOOTP
- Frame Relay
 - direct access PVC, 1-9
 - group access PVC
 - example, 1-11
 - setting up, 4-19 to 4-21
 - settings, 5-5
 - worksheet, B-9
- frames, displaying, A-14

G

- gateway, 4-14
- get command, A-8
- getcfg command, 5-6, A-2, A-10
- getting help
 - from a Bay Networks Technical Response Center, xix
 - through CompuServe, xvii
 - through InfoFACTS service, xviii
 - through World Wide Web, xviii
- group access. *See* Frame Relay

H

- hd (home directory) tag, in bootptab, 3-6

- HDLC encapsulation, 5-4
- History Control group, 6-9, 6-25
- home directory tag, 3-6
- Host group, 6-9, 6-26
- HostTopN group, 6-10, 6-27
- HP 9000. *See* HP-UX
- HP-UX
 - adding a TFTP user, 3-10
 - BOOTPD, 3-2
 - TFTPD access, 3-9

I

- ifconfig command, 5-3
- Image Builder default directory, 4-3
- image, software
 - corrupted, A-15
 - generating, 4-3
 - getting from a BOOTP server, 1-13 to 1-15
 - preparing, 4-3
 - specifying location of, 5-2
 - transferring, C-2
 - upgrading, A-15
- implementation notes, 6-23, C-2
- incoming interface, specifying, 4-15 to 4-18
- inetd.conf file, 3-3
 - loading changes, 3-11
 - setting up static routes, 3-11
 - troubleshooting, A-4
- InfoFACTS service, xviii
- initial startup options, 2-1
- Input IP Address parameter, 4-18
- interface connections
 - AUI port, 1-1, 1-3
 - Ethernet, 1-1
 - Ethernet repeater ports, 1-3
 - synchronous, 1-1
 - Token Ring, 1-1
 - UTP, 1-3

- interfaces
 - BOOTP parameters, 4-18
 - incoming and outgoing, 4-15 to 4-18
- interoperability issues for RMON, 6-23 to 6-29
- IP address, 1-9 to 1-13
 - assigning manually, 2-7
 - DLCI, 4-19 to 4-21
 - failure, A-2
 - getting automatically, 1-10 to 1-13
 - input parameter, 4-18
 - manual assignment, 5-3
 - options for getting, 5-3
 - EZ-Install, 1-9
 - Local Boot, 1-8, 1-15, 2-3
 - output parameter, 4-18
 - tag, 3-5
- IP interface
 - Ethernet
 - address settings, 5-6
 - connector setting, 5-6
 - synchronous
 - connector setting, 5-5
 - default settings, 5-4
- IP routes
 - changing, 3-10
 - displaying, A-13
- ip tag, in bootptab, 3-5
- ISDN BRI, 1-4

K

- kernel file. *See* `krnl_an.exe`, 1-6
- `krnl_an.exe`, 1-6
 - generating, 4-3
 - specifying instead of `an.exe`, A-3
 - upgrading, A-15

L

- LAN protocol analyzer, A-8, A-9
- line usage, minimizing
 - bandwidth, 2-5

- cost, 2-4
- link module, B-3
- linking ANHs, C-6 to C-9
- linking BOOTPD and TFTPd, 3-9
- LMI, Frame Relay, 5-4
- Local Boot
 - configuring, B-1
 - definition, 1-6
 - initial startup option, 2-9
 - starting, B-12
 - summary, 1-8
- local file system, mounting, B-12
- log command, A-8

M

- Matrix group, 6-10, 6-27
- memory
 - allocation hints, C-2
 - preventing saturation, 1-8, 2-4
- memory use for RMON, 6-23 to 6-29
- MIB
 - router support, 1-5
- minimizing cost of line usage, 1-8, 2-4
- modem port, 1-1

N

- N11 DCM option. *See* DCM
- naming configuration files, 4-2
- Netboot, 1-13 to 1-15
 - adding an interface for, 4-8 to 4-13
 - configuring, 3-1, 5-1
 - configuring interfaces for, 4-1, 5-2
 - definition, 1-6
 - ifconfig command, 5-2
 - requirements for, 1-8
 - summary, 1-8
- Netboot (cont.)
 - troubleshooting, A-3 to A-5

Netboot Global parameters

- Boot Config From Network, 4-6
- Boot Config Pathname, 4-7
- Boot Image From Network, 4-5
- Boot Image Pathname, 4-7
- Boot Server Address, 4-6
- editing, 4-4 to 4-7

Netboot Interface parameters

- Connector, 4-11
- Connector IP Address, 4-11
- Connector Next Hop, 4-12
- Connector Protocol Mask, 4-12
- Connector State, 4-13
- Connector Subnet Mask, 4-12
- Slot Number, 4-11

netstat command, 3-11, A-13

network analyzer, A-9

next-hop router

- configuring, 4-19
- not receiving BOOTP requests, A-2, A-3
- not sending BOOTP responses, A-2, A-4

O

operating systems, 3-2

options for getting startup files

- application files, 1-6
- Directed Netboot, 1-8
- EZ-Install, 1-7
- Local Boot, 1-8
- Netboot, 1-8
- string files, 1-6

options for getting the IP address

- Directed Netboot, 1-10
- EZ-Install, 1-10
- Local Boot, 1-15, 2-3
- Netboot, 1-10

OSPF, worksheet for, B-5

outgoing interface, specifying, 4-15 to 4-18

P

Packet Capture group, 6-10, 6-28

Packet Capture tool, A-8

packets

- analyzing, A-8
- displaying forwarded and dropped, A-14

parameters, displaying, A-10

pathnames, 1-13

- restrictions, 4-2

pointer tag, in bootptab, 3-5

port

- console, 1-1
- Ethernet repeater, 1-3, 6-1
- modem, 1-1

pound sign in bootptab file, 3-4

power loss while writing to a file, 2-4, A-16

PPP wide-area protocol, worksheet for, B-10

product series, 1-1

PVC. *See* Frame Relay

Q

Quick Get tool, A-8

Quick-Start

- commands, B-13
- defined, B-1
- install.bat script, B-12
- using, B-12

Quick-Start procedure

- worksheet, B-3 to B-4

R

reboot

- DCM, 6-12

receive socket, BOOTP, 3-2

relay agent forwarding table. *See* BOOTP

remote dialup, A-7

- repeater ports, Ethernet, 1-3
 - ANH support, 1-3
 - enabling, 6-4
 - resetting, 6-3
 - testing, 6-3
- Request for Comments 1757, 6-7, 6-9
- Reset parameter, 6-3
- resetting and testing ANH, 6-1 to 6-3
- resetting while writing to a file, 2-4, A-16
- RFC 1048, 3-6
- RIP routing protocol, worksheet for, B-5
- RMON
 - agent, 6-8
 - control parameters, 6-9
 - control tables, 6-9
 - data tables, 6-9
 - groups, 6-8 to 6-10
 - interoperability issues, 6-23 to 6-29
 - memory use, 6-24 to 6-29
- RMON Default Host parameter, 6-16
- RMON Default Matrix parameter, 6-17
- RMON Max Host parameter, 6-16
- router software image
 - definition of, 1-6
- routine startup options, 2-3
- RS/6000. *See* AIX

S

- saturation of router memory, preventing, 2-4
- See also* Quick-Start
- Selftest, ANH parameter, 6-3
- send socket, BOOTP, 3-2
- slot number, B-3
- Slot Number parameter, 4-11
- sm (subnet mask) tab, in bootptab, 3-5
- SMDS wide-area protocol, worksheet for, B-12
- sniffer. *See* LAN protocol analyzer

- SNMP implementation notes, 6-23
- sockets, BOOTP, 3-2
- software, configuration
 - Diagnostics Monitor, 1-5
 - Site Manager, 1-5
 - Technician Interface, 1-5
- Solaris
 - copying BOOTPD, 3-2
 - TFTPD access, 3-9
- SQE test, disabling for AUI port, C-8
- startup options
 - displaying, A-10
 - initial, 2-1
 - EZ-Install, 2-6
 - Local Boot, 2-9
 - Netboot, 2-7, 2-8
 - Local Boot, 1-15
 - Netboot, 1-9
 - routine
 - Directed Netboot, 2-4
 - Local Boot, 2-5
 - Netboot, 2-3
 - selecting, 2-1
 - Local Boot, 2-3, 2-5, 2-6
 - Netboot, 2-3, 2-6
- static routes, 3-10
- Statistics Manager tool, A-8
- string files, 1-6
 - generating, 4-3
- subnet mask tag, 3-5
- Sun workstations, 3-2
- SunOS
 - copying BOOTPD, 3-2
 - TFTPD access, 3-9
- symbols in bootptab file, 3-4

- synchronous interfaces, 1-1, 1-3
 - configuring, 5-4
 - displaying MIB entry, A-7
 - ifconfig settings, 5-4
 - support
 - EIA232, 1-3
 - EIA449/422, 1-3
 - V.35, 1-3
 - X.21, 1-3
- syntax of bootptab file, 3-4
- System Administration Manager, HP 9000, 3-10

T

- T130 size tag, in bootptab, 3-5
- table continuation tag, 3-5
- tags in bootptab, 3-6
 - format, 3-4
- tc (table continuation) tag, in bootptab, 3-5
- TELNET, B-4
- testing BOOTP, C-1
- testing IP interface during Quick-Start, B-14
- TFTP
 - adding an HP 9000 user, 3-10
 - default volume, B-4
 - example, 1-14, 1-15
 - interruption, A-15
 - transferring image, C-2
- TFTPD
 - linking to BOOTPD, 3-9
 - setting up, 3-8 to 3-12
- tg variable in bootptab file, 3-4
- Timeout Secs. parameter, 4-16
- Token Ring interfaces, 1-1
 - limitation, C-2
- troubleshooting, A-1 to A-14

U

- UDP, 3-2
- underscore symbol in bootptab file, 3-5
- UNIX workstation, 3-1
- unshielded twisted pair, 1-3
- upgrading image, A-15
- upstream router, 1-9, 4-19
 - not receiving BOOTP requests, A-2, A-3
 - not sending BOOTP responses, A-2, A-4
- UTP interface, 1-3

V

- vendor magic field, 3-6, A-12
- versions of software, 2-6, 2-7, 4-3, C-2
- vm (vendor magic) tag, in bootptab, 3-6
- volume, specifying, A-15

W

- wfBootpRelayIntfEntry, A-14
- wfCSMACDEntry, A-7
- wfDrivers, A-6
- wfSyncEntry, A-7
- World Wide Web, Bay Networks Home Page on,
xviii